




# SP (SelectAire Plus™) Series Energy Recovery Natatorium Dehumidifiers

## *Installation and Operation Manual*

- Select Aire Plus™ (SP) systems are dual refrigeration circuit dehumidifiers with latent energy enhancement.
- Cabinet has injected foam double wall panels for high insulation properties and strength.
- Refrigeration circuits contain scroll compressors for high performance and long life.
- Model features passive latent heat enhancement device for high moisture removal capacity.
- SP systems include an exclusive exhaust air heat recovery system and air flow balancing.
- SP's dual refrigeration circuit design allows staging to minimize energy consumption and optimize energy recovery.



**SELECT AIRE™**  
—PLUS— by Desert Aire





## DANGER

ONLY TRAINED, QUALIFIED PERSONNEL SHOULD INSTALL AND/OR SERVICE DESERT AIRE EQUIPMENT. SERIOUS INJURY, DEATH AND PROPERTY DAMAGE CAN RESULT FROM IMPROPER INSTALLATION/SERVICE OF THIS EQUIPMENT. HIGH VOLTAGE ELECTRICAL COMPONENTS AND REFRIGERANT UNDER PRESSURE ARE PRESENT.

# Desert Aire Dehumidification Equipment Standard Limited Warranty

Desert Aire warrants the dehumidifying unit to be free from defects in materials and workmanship subject to the terms, conditions and limitations stated herein.

## TERMS

Desert Aire warrants all components (except as noted) for a period of two (2) years from the date of shipment. This warranty shall be limited to the supply of new or rebuilt parts for the part which has failed because of defects in workmanship or material, and does not include the cost for labor, transportation or other costs not herein provided for. Replaced parts are warranted only for the remaining portion of the original warranty period.

## CONDITIONS

**The warranty is subject to the following conditions:**

1. The unit must be properly installed and maintained in accordance with the Desert Aire "Installation and Operation Manual" provided with each unit and/or other documentation provided.
2. **The Start-Up Report must be completed and returned to Desert Aire Service for evaluation. If no deficiencies are identified a Warranty Validation Letter will be issued that provides all warranty dates and coverage. If installation or start-up deficiencies are present, these must be corrected and communicated to Desert Aire in order to activate warranty.**
3. This warranty shall not apply to any part that has been tampered with, or has been subject to misuse, negligence or accident. A warranty can be obtained for altered equipment but only with written consent from Desert Aire.
4. The following parts and components are excluded from the warranty: belts, filters, driers, fuses and refrigerant.
5. Refrigerant coils or other components that corrode due to improperly balanced pool chemistry or corrosive air quality will not be warranted.
6. All replacements or repairs will be FOB Germantown, WI.
7. This warranty shall be null and void if defects or damages result from unauthorized opening of the refrigerant circuit, tampering with factory set controls, or operating outside the original design conditions.

8. Desert Aire shall not be liable for labor costs incurred in diagnosing the problem, or the removal or replacement of the part or parts being repaired.
9. Desert Aire must preauthorize all warranty coverage described herein.

**Extended Warranty:**

Your Desert Aire unit may have extended warranties beyond this Standard Limited Warranty document. Extended warranties are only available at the time of the purchase of the original equipment. These extended warranties are covered under a separate document and their terms and conditions are separate from this document. It is mentioned in this document for informational purposes only. Any Extended Warranties will be identified on the Warranty Validation Letter.

*Any and all incidental or consequential damages are expressly excluded from this warranty. Some states do not allow the exclusion of incidental or consequential damages for personal injury, so the above limitations may not apply to you for certain damages. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. No person or representative is authorized to make any warranty or assume any liability not strictly in accordance with the aforementioned.*

Inquiries regarding warranty matters should be addressed to:

Desert Aire Corp c/o Service Manager  
N120 W18485 Freistadt Road • Germantown, WI 53022  
PH: (262) 946-7400 • FAX: (262) 946-7401 • E-MAIL: [service@desert-aire.com](mailto:service@desert-aire.com)

Additional copies of this manual can be purchased for a nominal fee from Desert Aire. Desert Aire also posts the most current revision of our I/O Manuals on our website. For a digital copy of the I/O Manual for your unit revision, please submit request to the contact information listed above.

**Gas Heat Exchanger Ten (10)-Year Prorated Warranty Terms (For units with gas heat only)**

Desert Aire offers an extended prorated eight (8)-year warranty for gas heat exchanger. All other heater components are covered under the initial 2 year warranty.

**2 Years Parts Only from date of shipment. Prorated from years 3-9 as follows:**

Year 3: Desert Aire warrants 70% of replacement price  
Year 4: Desert Aire warrants 60% of replacement price  
Year 5: Desert Aire warrants 50% of replacement price  
Year 6: Desert Aire warrants 40% of replacement price  
Year 7: Desert Aire warrants 30% of replacement price  
Year 8: Desert Aire warrants 20% of replacement price  
Year 9: Desert Aire warrants 10% of replacement price

## For Units w/ Gas Heat:

### For Your Safety Read before Operating



## **WARNING: FIRE OR EXPLOSION HAZARD**

Failure to follow safety warnings exactly could result in serious injury, death or property damage.

Be sure to read and understand the installation, operation and service instructions in this manual.

Improper installation, adjustment, alteration, service or maintenance can cause serious injury, death or property damage.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

### **WHAT TO DO IF YOU SMELL GAS**

- Do not try to light any appliance
- Do not touch any electrical switch; do not use any phone in your building
- Leave the building immediately
- Immediately call your gas supplier from a phone remote from the building.  
Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

Installation must be performed by a qualified installer, service agency or gas supplier.

More safety information is included in the gas furnace manual; therefore, it must be kept with the appliance for future reference.

- A. The included gas fueled furnace(s) does not have a pilot. It is equipped with a direct spark ignition device that automatically lights the burner. **DO NOT** try to light the burner by hand.
- B. BEFORE OPERATING, leak test all gas piping up the heater gas valve. Smell all around the unit area for gas. **DO NOT** attempt to place heater in operation until source of gas leak is identified and corrected.
- C. Use only hand force to push and turn the gas control knob to the "ON" position. **NEVER** use tools. If the knob will not operate by hand, call a qualified service technician to replace the gas valve prior to starting the unit. Forcing or attempting to repair the gas valve may result in a fire or explosion.


- D. Do not attempt to operate unit, if there is indication that any part has been under water. Any control or component under water must be immediately replaced by a qualified service technician prior to trying to start the unit.

## OPERATING INSTRUCTIONS


1. STOP! Read the safety information above on this label and Refer to individual furnace Sequence of Operation to determine manifold pressures at start-up and during operation on the modulating furnace.
2. Set the thermostat to lowest setting.
3. Turn off all electric power to the appliance.
4. This appliance is equipped with an ignition device that automatically lights the burner. **DO NOT** try to light the burner by hand.
5. On 2-stage units, turn gas control knob clockwise to “OFF” position or switch down for single stage.
6. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, STOP! Follow “B” in the safety information above on this label. If you don’t smell gas, go to next step.
7. Turn gas control knob counterclockwise to “ON” position on 2-stage units or flip up to “ON” for single stage units. **NOTE: DO NOT FORCE.**
8. Turn on all electric power to unit.
9. Set thermostat to desired setting.
10. If appliance will not operate, follow the instructions “To Turn Off Gas To Appliance” and call your service technician or gas supplier.

## TO TURN OFF GAS TO APPLIANCE


1. Set thermostat to lowest setting.
2. Turn off all electric power to the appliance if service is to be performed.
3. On 2-stage units, turn gas control knob clockwise to “OFF” position or switch down for single stage. **DO NOT FORCE.**



On / Off (1 Stage) Gas Valve



2 Stage Gas Valve



*Honeywell V8944 Gas Valve for 500,000 and 600,000 models*

**Product Warning for the State of California:**



**WARNING:** Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)



## TABLE OF CONTENTS

1	Introduction .....	13
1.1	Inspection .....	13
1.2	Freight Damage Claims .....	13
1.3	Rigging .....	13
1.3.1	Rigging the Dehumidifier .....	13
2	Installation .....	15
2.1	Position and Service Clearance .....	15
2.2	Outdoor Air and Exhaust Air .....	19
2.2.1	Indoor and Outdoor Installation .....	19
2.3	Condensate Drain Piping .....	21
2.4	Tower and Pool Water Piping .....	23
2.4.1	Tower Water Piping (Optional) .....	23
2.4.2	Pool Water Piping (Optional).....	24
2.5	Auxiliary Air Heat Coil Piping .....	26
2.6	Remote Condenser (Optional) .....	27
2.7	High Voltage Wiring .....	27
2.8	Controls and Sensors .....	28
2.8.1	Air Temperature/Humidity Sensors .....	29
2.8.2	Water Temperature Sensor .....	31
2.8.3	Installation of Sensors for the SelectAire Plus™ .....	32
2.8.3.1	Indoor Static Sensor Installation .....	32
2.8.3.2	Outdoor Static Sensor .....	33
2.8.4	Installation of VOC Monitoring Sensor .....	34
2.9	Auxiliary Heating Control Wiring .....	35
2.9.1	Auxiliary Heating - Dry Contact Closure .....	35
2.9.2	Auxiliary Heating - Proportional Signal .....	35
2.10	Gas Heater (Optional) .....	36
2.10.1	Gas Heater Installation Safety .....	36
2.10.2	Gas Piping .....	37
2.10.3	Gas Heater Location .....	42
2.10.4	Gas Furnace Venting .....	45
2.10.4.1	B-Vent Parts .....	45
2.10.4.2	B-Vent Assembly Instructions .....	45
2.10.5	Indoor Unit Set-up Instructions .....	47
2.10.6	Finalize Installation .....	47
2.10.7	Gas Heater Start-up .....	47
2.10.8	Gas Heater Condensate Drain .....	48
2.10.9	Induced Draft Fan .....	49

2.11	Auxiliary Pool Water Heating .....	49
2.12	Smoke Alarm Interlock .....	49
2.13	Auxiliary Air Heater - Hot Water Coils .....	50
2.14	Packaged Condenser Hail Guard and Pre-Filter Assembly Instructions .....	50
2.14.1	Packaged Condenser Hail Guard .....	50
2.14.2	Packaged Condenser Pre-Filters .....	51
2.14.2.1	Mounting .....	51
2.14.2.2	Inspection .....	51
2.14.2.3	Cleaning .....	51
2.15	Section Cabinet Assembly Instructions (Optional) .....	52
2.15.1	Rigging Instructions .....	52
2.15.2	Cabinet Assembly .....	52
2.15.3	Refrigeration Piping Reassembly (when applicable) .....	55
2.15.4	Drain Piping Reassembly (when applicable) .....	58
2.15.4	Refrigeration System Evacuation / Preparation for Operation (when applicable) .....	58
2.15.6	Electrical Wiring / Airflow Tubing Assembly .....	59
2.15.7	Reconnect Differential Pressure Tubing (if applicable) .....	60
2.16	Hood Assembly Instructions (if applicable) .....	60
2.16.1	Outdoor Air Hood Assembly (if applicable) .....	60
2.16.2	Exhaust Hood Assembly Instructions .....	60
2.16.2.1	Standard Exhaust Hood Option .....	60
2.16.2.2	Right or Left Exhaust Hood Option .....	62
2.17	Combination Moisture and Liquid Indicator .....	63
2.18	Crankcase Heaters, Heat Tape, GFI Outlets and Lighting .....	64
2.18.1	Crankcase Heaters and Heat Tape .....	64
2.18.2	GFI Outlets and Lights .....	64
2.18.2.1	Dedicated 120V AC Powered Lights, GFI, and Receptacle (Standard) .....	64
2.18.2.2	GFI and Lights Powered by the Dehumidifier (Optional) .....	64
2.18.3	Receptacle for Gas Heat Trap Heat Tape (Outdoor Units Only) .....	64
2.19	Vestibule Cabinet Vent Fans (Non-Packaged Units) .....	64
2.19	Rain Guard Hood Installation .....	65
3	Start-Up and Maintenance Procedures .....	66
3.1	Preliminary Inspection .....	66
3.2	Airflow Balancing .....	66
3.2.1	Airflow Setup of SelectAire Plus™ .....	67
3.2.2	Final Air Balancing .....	71
3.3	Refrigeration Testing .....	75
3.4	General Testing .....	76

3.5	Routine Maintenance Schedule .....	77
3.5.1	Service Every Month .....	77
3.5.2	Service Every Four Months .....	77
3.5.2.1	Reheat Condenser Coil Cleaning .....	77
3.5.2.2	ElectroFin Coated Coil Cleaning .....	79
3.5.3	Service Every Six Months .....	82
3.5.4	Blower / Fan Maintenance .....	83
3.5.5	Auxiliary Heater – Hot Water Coil Maintenance .....	84
3.6	General Service .....	86
3.6.1	Filter Drier Replacement .....	86
3.6.1.1	When to Change Cores .....	86
3.6.1.2	Instructions for Assembly and Charging Cores .....	86
4	Troubleshooting .....	89
4.1	The Blower Does Not Run .....	89
4.2	The Compressor(s) Do Not Run .....	89
4.3	High Pressure Alarms / Readings Above 575 PSIG .....	90
4.4	Low Pressure Alarms / Evaporator Coil Icing .....	91
4.5	The Pool Water Is Too Cold .....	91
5	Appendix .....	93
5.1	Compressor Failure .....	93
5.1.1	Compressor Replacement .....	93
5.2	Recommended Duct Design .....	96
5.3	Pool Water Chemistry .....	97
5.4	Recommended Controller Settings .....	97
5.4.1	Controller Set Points .....	97
5.5	System Operating Modes .....	97
5.5.1	Basic Sequence .....	97
5.5.2	Blower Operation .....	99
5.5.3	Dehumidifier Operation .....	100
5.5.4	Cooling Operation .....	100
5.5.5	RecoverAire (ER) Energy Recovery Operation .....	100
5.5.6	Damper Operation .....	100
5.5.6.1	Outdoor Air and Outside Air Bypass Dampers .....	100
5.5.6.2	Evaporator Bypass and Thru Dampers .....	101
5.5.6.3	Exhaust Dampers .....	101
5.5.7	Examples of Cooling and Dehumidification Operation.....	101
5.5.8	Heating Operation .....	102
5.5.9	Suction Pressure Operation .....	104
5.6	Component Replacement, Charge, Evacuation, & Leak Instructions .....	104

5.7	System Rating Plate .....	108
5.8	Start-Up Supervision Supplemental Information .....	109
5.9	LC/LV/SA/SP Start-Up Report .....	110
	System Start-Up Report .....	112
	Start-Up Report .....	113
	Compressor Replacement Form .....	121

# 1 Introduction

Desert Aire dehumidifiers are designed to provide years of reliable service when installed properly. Read these instructions carefully before you install the dehumidifier.

## 1.1 Inspection

Desert Aire inspects and tests each dehumidifier before it leaves the factory so that you receive a quality piece of equipment. Unfortunately, equipment may become damaged in transit. Inspect the dehumidifier carefully before signing the receiving papers. Check for both visible and concealed damage. Use a halogen leak detector to check the piping for refrigerant leaks.

## 1.2 Freight Damage Claims

If the dehumidifier has been damaged, document the extent of the damage. Take pictures if possible. Next, obtain a claim form from the carrier. Promptly fill out and return the form. Carriers may deny claims if the form is not filled out within a week of delivery. Notify Desert Aire of any damage.

## 1.3 Rigging

### **WARNING**

1. **Failure to observe rigging instructions may lead to equipment damage, personal injury or death.**
2. **Lifting method and procedure must comply with all local and national codes and regulations.**
3. **The use of safety slings in addition to lifting lugs is required.**
4. **Do not lift the dehumidifier in high winds or above people.**

Desert Aire dehumidifiers are solidly built and can be very heavy. Avoid personal injury and damaged equipment by planning the installation carefully. Use moving equipment whenever possible.

### 1.3.1 Rigging the Dehumidifier



Desert Aire dehumidifiers are equipped with four or more lifting lugs. Use spreader bars and safety straps when you use these lugs for rigging.

- Utilize all of the lifting lugs provided when hoisting unit.
- Test-lift the dehumidifier to verify that it is properly balanced.
- Do not lift the dehumidifier in high winds or above people.
- The top panels are not designed to support the weight of persons. The top panels are weather proofed and excessive weight may cause water to penetrate through cracked seams. Damage incurred through caved or distorted top panels will not be covered under warranty. If you must walk on the top panels, carefully walk on the edges where structural integrity is greatest.

# Large System Rigging

## Notes:

1. The number of lifting points will vary between units. All lifting points must be used to lift unit.
2. Spreader bar must be used. Unit top panel is not designed to handle loading.
3. Lifting method/procedure to comply with all local and national regulations.
4. Use safety slings (not shown) in addition to lifting lugs.
5. Be sure that the lifting hooks do not contact the sides of the unit.
6. Use appropriate lifting strategy for unit.



0036.cdr

Figure 1 – Typical Rigging for the SP Dehumidifier

## CAUTION

1. **Do not tip the dehumidifier on it's side.**
2. **Avoid dropping the unit down stairways or subjecting it to severe mechanical shock.**

## 2 Installation

This Installation and Operations Manual applies to standard unit configurations only.

### 2.1 Position and Service Clearance

Desert Aire dehumidifiers require routine maintenance to operate efficiently. Always refer to the General

Arrangement drawings for recommended clearance distances that are specific to your unit.

- Allow a minimum of 36 inches of clearance around the service side of the dehumidifier for piping, electrical connections, and service access. Install the unit on a sturdy, level mounting base or platform that will prevent vibration and sound transmission. Never install the dehumidifier on a wooden platform without consulting the design engineer for spring isolation requirements and sound control materials. Do not install the unit near occupied rooms such as offices or guest rooms.
- Level the dehumidifier to ensure proper condensate drainage.
- Install blocks under the unit if necessary to provide clearance for the condensate trap. Install blocks underneath each corner and each lifting lug.




Figure 2 – Dehumidifier with Blocks Installed for Trap Clearance

- Install outdoor dehumidifiers equipped with an outdoor air intake away from plumbing vents, furnace flues, or equipment which could contaminate the air supply.
- If the dehumidifier is to be mounted on a roof curb, make sure that the curb has been properly mounted and supported. Place gasket material around the perimeter of the curb before setting the dehumidifier in place. This will help prevent air or water leaks.
- You must not install an indoor rated dehumidifier in an unconditioned space or where ambient temperatures can fall below 45°F. If you must install the dehumidifier outside or in an unconditioned space, you must use an outdoor rated dehumidifier. Desert Aire recommends that all condensate lines on outdoor-rated units be heat-traced and covered with weather-proof insulation material. You can determine if your unit is outdoor-rated by inspecting the unit rating plate. See *Section 5.6* for details.
- Duct design and installation should conform to ASHRAE and SMACNA low velocity duct standards. See *Section 5.2* for additional duct recommendations.




Figure 3 – Basic Pool Room Layout



Use turning vanes whenever the duct makes an abrupt turn, especially in the return air duct.  
 Poor return air distribution will reduce the moisture removal.




Figure 4 – Typical In-Ground Duct Layout

- You may use galvanized sheet metal ducts for all but underground installations and severely corrosive environments.
- Do not use fiberglass duct boards or acoustic duct liner for air distribution in highly humid applications, such as pool room dehumidification.
- If a duct must be installed in an unconditioned area, or if you are installing an outdoor air intake duct, insulate it with two inches of fiberglass duct wrap with an intact vapor barrier.
- Direct the supply air toward skylights, exterior walls and windows, and spectator areas. Since air movement will increase the evaporation rate of the pool, direct the supply air grilles away from its surface.




Figure 5 – Soffit Duct Layout with Skylight Grille

- Install return air grilles or louvers as high as possible in the enclosure. Normally, one centrally-located grille will be adequate. Avoid under sizing this grille or “short-circuiting” of air with nearby supply registers.
- Select grilles and diffusers for low static pressure loss and proper throw and CFM rating.
- Keep the noise criteria levels of the grilles between 35dB and 45dB.
- Use anodized aluminum grilles to prevent premature corrosion.

## **2.2 Outdoor Air and Exhaust Air**

Desert Aire SelectAire Plus™ dehumidifiers are equipped with an opening which will draw outdoor air into the conditioned space. This will help you comply with ASHRAE Standard 62, which requires the introduction of outdoor air into commercial buildings.

Additionally, the SelectAire Plus™ unit is equipped with fans and dampers for exhausting air from the building. This ensures that the building is at a negative static pressure relative to adjacent spaces and outdoors.

Several modes may be available that provide for different outside air and exhaust flow rates. These modes are Unoccupied mode, Occupied mode, Event mode, Purge mode and Max OA mode. See *Section 5.4.1* for more details.

The ducting method you use depends on the SelectAire Plus™ type of dehumidifier you purchased.

### **2.2.1 Indoor and Outdoor Installation**

A SelectAire Plus™ unit configured for indoor installation has a module which contains filters and a factory-installed damper and actuator. The outdoor air is distributed between the evaporator and the reheat condenser coils. The unit controller will energize dry contacts to control any additional outdoor air dampers. This controller will also control the internal exhaust fans. Figure 6 shows typical ducting for the SelectAire Plus™ unit configured for indoor installation. The outdoor air duct used for indoor units must be insulated to prevent condensation from forming on it during the winter. Since cold outdoor air can cause moisture to condensate and freeze on surfaces when it mixes with the warm, humid return airstream, you must preheat the outdoor air whenever possible.

When equipped for indoor installation the SelectAire Plus™ unit will also have a connection for the exhaust air duct. The humid exhaust air may form an icy fog when it blasts outside during the winter. Install the outlet grille in a location where this fog will not damage the building or create a safety hazard. The SelectAire Plus™ has several options for location of the exhaust air discharge. See submittal documentation and general arrangements for locations of connections for a particular unit.




Figure 6 - Indoor Dehumidifier Showing Outdoor Air and Exhaust Duct

A SelectAire Plus™ unit configured for outdoor installation has an outdoor air intake that is protected by dual weather hoods. The unit controller will control the internal outdoor air damper and the exhaust blower configuration. Dry contacts are available for control of field supplied dampers.

An outdoor SelectAire Plus™ unit is also provided with an exhaust hood. This is shipped loose for field installation. See *Section 2.16* for installation instructions.




Figure 7 – Outdoor Dehumidifier

The outdoor air hoods are equipped standard with a wire mesh (bird screen) material attached to a rack at the lower face of the hood. If needed, the rack can be removed from the hood for cleaning as an assembly. There are several 1/4 – turn fasteners at the perimeter of the rack that can be removed. The rack will then tilt downward and can be pulled out from the face of the cabinet.


An optional outdoor air pre-filter may also be included in the rack. The rack can be removed in a similar fashion for basic cleaning. Particulate such as cottonwood, airborne seeds, or

dust can often be wiped or vacuumed off of the surface of the filter.

If a more thorough cleaning is warranted, the pre-filter can be removed from the rack by removing the 1/4 – turn fasteners holding the screen to the rack. Use Dawn® liquid detergent and hose directed water to clean the pre-filter if there is an accumulation of dirt or other contaminants.


### 2.3 Condensate Drain Piping

The condensate drain connection on the standard Desert Aire SelectAire Plus™ series dehumidifiers is a 1-1/2" PVC stub which penetrates the evaporator wall section on the access side of the unit, see Figure 8.



*Figure 8 – SP Standard Condenser Drain Location*

An SP series dehumidifier ordered for roof curb mounting has its drain connection on the underside of the unit to help prevent freezing, see Figure 9. Note that upon customer requests that this connection may be installed on the side of the unit. When this is requested, additional precautions against freezing and ice accumulation may be required when the outdoor air temperature drops below 32°F.



*Figure 9 – SP Roof Curb Unit Showing Condensate Drain Location*

Connect the trap to a main drain line with 1/4" of downward pitch per linear foot of run. Support the drain pipe every five feet to prevent line sagging.

The SelectAire Plus™ units are equipped with internal condensate traps to allow for proper unit function. These are conservatively sized to handle the negative static pressure that was specified at the time of order.

**Do not install a second trap external to the equipment as this may cause a pocket of air to be formed. Water will back up into the pan and equipment and/or building damage will occur.**

Internal condensate traps require priming before unit operation. Pour enough water into each evaporator drain pan until water flows from the end of the condensate drain line.

There is a drain pan located under the internal reheat condenser coil. Its purpose is for draining water away during cleaning of the reheat coils. For convenience this is piped to the same drain as the condensate. If you wish to use the drain pan during cleaning, ensure that the cleaning solutions and the contamination to be washed from the coils will not cause any issues for the existing drain system. If the condensate is being recycled in any manner or the system leads to a sanitary sewer system, draining the products of the cleaning process may not be appropriate. If the drain is to be used, open the valve that allows water from the lower coil pan to enter the condensate system and proceed with the cleaning process. Note that once complete, the valve must be returned to a closed position to provide for proper operation of the condensate traps when the unit is turned on.

See *Section 2.10* for condensate line instructions for auxiliary gas heating if equipped.

## CAUTION

Condensate drain lines installed in an unconditioned space must be heat taped to prevent freezing. Check the heat tape yearly before winter operation.

### 2.4 Tower and Pool Water Piping (Optional)

#### 2.4.1 Tower Water Piping (Optional)

As an option, the dehumidifier may be equipped with a tower water condenser. Use industry standard piping practices when connecting such to the dehumidifier. Connections are copper stubs. Refer to submittal documentation for specific size per model.

#### Water Quality and General System Design

A 60 mesh or finer strainer must be installed in the water inlet line. Flush field installed piping thoroughly before you put the dehumidifier into service. A piping system that is not properly flushed or filtered will cause the blazed-plate heat exchanger to lose efficiency or fail prematurely due to clogging and/or fouling.

To prevent premature failure of the tower water heat exchanger, maintain the water at a pH of 7.4, but never below 6.0. Do not use water with high concentration of sulfur, chlorine, or sodium chloride.

A dedicated circulating pump must be used unless the main pump can develop enough head to overcome the combined resistance of the water condenser and the piping connected to it. See *Section 2.4.2* for the required water flow rate and head pressure for your application.

Install an air eliminator at any high point in the water piping. Air trapped in the water circuit of the dehumidifier can lead to elevated operating pressures, unexpected service calls, and decreased equipment life.

If the water system is connected to a variable frequency drive or to water loops with multiple units, flow regulating valves should be installed to ensure flow rate is maintained.



## CAUTION

Do not exceed guidelines as excessive flow rates will erode the condenser and piping.

### 2.4.2 Pool Water Piping

The Desert Aire dehumidifier may be equipped with an optional pool water heating condenser. Use copper or schedule 80 CPVC pipe and fittings to adapt to the water circuit of the dehumidifier. See Figure 10 for recommended pool water piping. Note that this figure is intended to be a general guide only, and may not match your installation exactly.

All piping must meet state and local codes.


## CAUTION

**120V / 15A Power Connection. Power is required for water heat exchanger when equipped. Damage caused by freezing is not covered under warranty. Check power and operate regularly.**

- You may not need an auxiliary pump if the main pool pump has sufficient pressure to overcome the elevation and the resistance of the water piping to the dehumidifier. If the main pump will be cycled on and off, you must use an auxiliary pump.
- If you use an auxiliary pump and you intend to cycle the main pump, you must size the auxiliary pump to overcome the resistance of the main pool piping and filters.
- The dehumidifier is equipped with a built-in flow switch. If there is no water flow to the unit, the refrigeration circuit will be locked out of the pool water heating mode. All other modes, such as dehumidification and cooling, will function normally. Desert Aire recommends continuous water flow to the unit to prevent vapor lock, pump cavitation, and nuisance head pressure trips.
- You must install an air eliminator at any high points in the pool water piping. Excess air in the Desert Aire pool water condenser will cause inadequate pool heating and high operating temperatures and may shorten the life of the dehumidifier.

The dehumidifier may be equipped with pool heating on one or more circuits. When pool water heating is included a factory supplied water temperature sensor and an aqua stat well will be supplied, per pool water circuit. See *Section 2.8* for details on control and sensor location.





1	Supply Air
2	Duct Heaters (Gas, Electric, Etc.)
3	Flex Duct Connector
4	Piping to Remote Condenser
5	SP Dehumidifier
6	Filter Rack Assembly with Filters
7	Return Air
8	Vibration Isolators
9	P-Trap
10	Base (If Required)

11	Check Valve
12	Ball Valve
13	Flow Meter
14	Main Pool Heater
15	Auxiliary Pump
16	Filter Assembly
17	Main Pool Pump
18	Water Temp Sensor (Dry Well)
19	Water Inlet
20	Water Outlet

Figure 10 – Typical Pool Water Piping Diagram

Circuit	Pool Water Flow Rate and Pressure Drop
45A	30 GPM @ 25 ft. W.C.
45B	50 GPM @ 25 ft. W.C.
50A	40 GPM @ 25 ft. W.C.
45B, 50B, 60A	50 GPM @ 25 ft. W.C.
60B, 70A, 80A	60 GPM @ 25 ft. W.C.
70 B	70 GPM @ 25 ft. W.C.
80 B	80 GPM @ 25 ft. W.C.

Figure 11 – Standard Unit Water Flow Rates (for Units Equipped with this Option)

## 2.5 Auxiliary Air Heat Coil Piping (Optional)

The Desert Aire dehumidifier may be equipped with an optional hot water or steam air heating coil. This coil, when properly sized, will provide space heating during the winter months.

- You must use proper practice when you design and install the coil piping to prevent poor coil performance, shortened service life, or damage to the coil.
- The supply connections must not be supported by the coil headers.
- The control valve should be sized according to the pressure and flow rate requirements, not the coil connection size.
- On steam systems, size the trap for at least 2-1/2 times the design condensing rate to allow for high condensate flow on system start-up.
- On steam systems, use strainers, dirt pockets, and isolation valves to prevent clogging the control valve and to simplify service.
- Install swing joints in the connection piping to prevent damage to the coil header for thermal expansion.
- Use a backup wrench on the pipe stubs when attaching connections to prevent damage to the header.

See Figure 12 to review the 3-way valve piping configuration. The piping from the hot water coil to Port A and from the hot water coil to Port B will be factory piped. The Return water piping from Port C and Supply water piping from Port B will be field installed.




Figure 12 – Typical Three-Way Valve Application

## 2.6 Remote Condenser (Optional)

**Important:** Refer to the separate Air Cooled Condensers Installation and Operation manual for additional details on line design, traps, clamping, and other condenser installation requirements. Desert Aire SP series dehumidifiers are pre-charged with enough refrigerant to fill the Remote Condenser and up to 50 feet of refrigerant lines. No additional charge is required unless your line set is longer than 50 feet. Figure 13 below indicates the tubing diameters to be used up to 50' in length.

Linesets longer than 50 feet may require additional oil and refrigerant charge at the time of field installation. Line diameters may also be larger than the table below. Refer to the submittal documentation or label adjacent to the remote condenser connections to confirm the charge and lines for those systems.

SP Series Remote Condenser Line Size (R-410A)				
Model	Circuit A		Circuit B	
	Hot Gas Line (Discharge)	Liquid Line (Return)	Hot Gas Line (Discharge)	Liquid Line (Return)
SP45	1-1/8	3/4	1-1/8	7/8
SP50	1-1/8	7/8	1-1/8	7/8
SP60	1-1/8	7/8	1-5/8	1-1/8
SP70	1-5/8	1-1/8	1-5/8	1-1/8
SP80	1-5/8	1-1/8	1-5/8	1-1/8

Figure 13 – Remote Condenser Line Size Summary (for Units Equipped with this Option). Performance rated at return air conditions of 82°F / 60% RH, 50' Actual Line Length / 62.5' Equivalent Line Length at the design air flow rate.

## 2.7 High Voltage Wiring

You must follow all local codes when you connect the high-voltage wiring to the dehumidifier. Attach the wires to the disconnect switch mounted on the electrical panel.

### WARNING

1. **Disconnect power before servicing. The unit contains high voltage wiring to the dehumidifier and moving parts which may cause serious injury or death.**
2. **Multiple power sources are present. Disconnect all electric power including remote disconnect and 120V power before servicing.**
3. **Failure to properly wire the dehumidifier may create the possibility of shock and can lead to premature system failure.**
4. **This unit contains VFD motor drive(s) and/or EC motors. Wait at least three minutes after disconnecting power to service motors or electrical components.**




Figure 14 – A Typical Desert Aire Disconnect

EC fans will run the correct direction regardless of the input power. The compressor must be “bumped” to determine if it is pumping correctly. Use the controller display to view the analog inputs and briefly energize one of the compressor contactors. The discharge pressure should increase and the suction pressure should decrease when phasing is correct. Do not run the compressors in reverse rotation for an extended period of time as damage will result.

To assist in compliance with NEC and local codes, a second lug connected to the service panel in equipment with pool water condensers is provided. This lug is intended to be connected to the pool equipotential bonding grid in the field when required by code. This also removes the possibility of differences in potential between metals in the pool water and the water condenser that may accelerate corrosion. The bonding lug should be connected to the equipotential grid with 8 AWG or larger solid copper conductor.

## 2.8 Controls and Sensors

The standard Desert Aire SP series dehumidifiers are controlled by a microprocessor controller. This controller monitors conditions such as room humidity and temperature and controls the dehumidifier accordingly. A separate controls manual has been provided. Refer to this separate CM3560 IO manual for controller and sensor specifications, operation, and options.




Figure 15 – A Typical Desert Aire Controller with Expansion Boards

### **2.8.1 Air Temperature/Humidity Sensors**

The air temperature and relative humidity are sensed by the control system throughout either a factory mounted return air temperature sensor or a field installed wall-mount sensor. The configuration was determined at the time of order.

#### **Factory Installed Return Air Temperature / Humidity Sensor**

If selected at the time of order, the sensor is already factory installed in the return air section downstream of the filter rack. When the controller is powered you will be able to immediately read the return air condition.

It should be noted that airflow must be present at all times to accurately read the zone condition with this configuration; therefore, fan cycling control is not to be used with this sensor option. Most commercial facilities require constant fan operation regardless of the occupancy.

#### **Wall Mounted Return Air Temperature / Humidity Sensor**

If your dehumidifier was ordered with a field-installed wall-mount humidity and temperature sensor, mount the sensor about five feet above the pool deck on an interior wall with natural air circulation.

Avoid the following locations:


- Hot spots near concealed heating pipes, warm air ducts, supply register outlets, or solar radiation.
- Cold spots due to a cold wall or drafts from stairwells, doors, windows, or supply register outlets.
- Dead spots such as behind doors or in corners where room air cannot circulate freely.

A supply air temperature sensor and duct holder is also provided to be installed downstream of any field provided heaters. Mount this in the supply duct and seal the penetration. Install at least 5 ft. downstream of all heaters and not in the "line of sight" of the heater elements as the radiant heat produced by the heater may affect the reading.

#### **Outdoor Air Temperature / Humidity Sensor**

The outdoor air temperature and humidity sensor is used to determine if the conditions of the outdoor air are suitable for utilizing the economizer function. This sensor and a connector are included inside the unit in the electrical compartment of the unit. A radiation shield is shipped separately from the unit.


It should be noted that the return sensors and the outdoor air sensors are digitally communicating devices that are physically the same, but are programmed with unique addresses. The outdoor air sensor will have a label indicating "ADDR 191".



*Figure 16 – Sensor Junction Box Location*

The junction box is mounted at the supply air end of the unit, see Figure 16. When using an outdoor installed SP unit it is recommended that the radiation shield and sensor assembly be mounted to the SP unit near the provided junction box. The outdoor air temperature / humidity sensor should be installed in the radiation shield. This assembly then should be installed outdoors near the dehumidifier when the SP unit is installed indoors.

The shield is included to prevent additional heat loading from the sun and to prevent direct moisture contact with the sensor. With the curved shape and color of the plates, air flow is able to move across the sensor to keep radiated temperatures from surrounding surfaces from affecting humidity readings.



*Figure 17 – Radiant Shield*

Follow these instructions for installation of the radiation shield:

1. Loosen plastic probe retainer on radiation shield by unscrewing two retainer screws.
2. Remove the plastic probe retainer and substitute with the two-sided plastic probe retainer that is included with the unit.
3. Slide humidity transmitter probe completely into radiation shield.
4. Screw plastic probe retainer to the radiation shield until the probe is firmly held in place. Do not over tighten the screws.
5. Integral pipe mounting hardware should be removed for surface mounting applications. To do this, remove the u-bolt and screw holding the pipe retaining bracket.
6. Mark the outer two holes of the mounting bracket on the flat surface.
7. Drill these two holes marked in the previous step.
8. Attach the radiation shield to the flat surface.
9. Wire the sensor harness to the junction box wires per the below color chart. For your convenience, the sensor wires are pre-installed to the SP control panel and terminate in a junction box with quick connect wire lever locks. The wiring color coding is as follows:

Junction Box	Sensor Harness
White	White
Green	Blue
Red	Brown
Black	Black

10. Attach the wire harness as shown in Figure 18 below to the T/RH 309 Sensor. The sensor has a female end and the male wire harness threads onto the T/RH 309 Sensor.



Figure 18 – T/RH Sensor and Wire Connector

### 2.8.2 Water Temperature Sensor

Desert Aire dehumidifiers ordered with the pool water heating option are supplied with a water temperature sensor and an aqua stat well.

- Screw the well into the adapter fitted into the pool water piping. The well is equipped with a 1/2" MPT connection.
- Install the sensor upstream from the dehumidifier such that the inlet water temperature is sensed. The auxiliary pool water heater should not be installed upstream of the dehumidifier. Install heater downstream or in parallel with the dehumidifier.
- The sensor must be installed in a location where it will accurately sense the pool water temperature. This means you must have continuous water flow at the sensor location.



### 2.8.3 Installation of Sensors for the SelectAire Plus™

In pool applications, it is critical to maintain negative space pressurization relative to adjacent spaces and the outside ambient. This prevents moisture laden air from being driven into the wall cavities and condensing. The SelectAire Plus™ unit includes provisions to measure the differential in static pressure between the space and the outdoors and helps to maintain this negative static pressure in the space.

#### 2.8.3.1 Indoor Static Sensor Installation

The indoor static pressure sensor should be mounted in a location not subject to damage from occupants. Place the sensor as far as practical from doors, grilles, and operable windows that may cause pressure fluctuations. Locate a minimum of 3' above the floor level in the pool area. Note that in rooms with extremely high ceilings (greater than 30') it is preferable to locate the sensor a minimum of halfway up the wall. This is due to building stack effect where the pressure may become higher at the ceiling than at the floor.

The sensor can be mounted directly to drywall or to a standard single gauge electrical box. 50' of 1/8" pressure tubing is supplied with the sensor.

- Route the tubing such that it will not be subject to damage.
- Do not directly attach the tube to surfaces that may become very cold such as suction lines or supply ducts as condensation may occur in the tubing.
- Connect the tubing to the static pressure differential transducer in the unit. The correct port is labeled for the indoor air sensor.





Figure 19 – Indoor Static Pressure Sensor (rear view)



### 2.8.3.2 Outdoor Static Sensor

A complication in measuring the building static pressure is the dynamic action of the wind. Measuring the wind's pressure instead of the true outdoor static pressure will alter the actual static pressure reading. Proper mounting of the outdoor static sensor will help ensure accurate readings.

The outdoor air static pressure sensor should be mounted at least 12 inches above surrounding obstacles and a minimum of 24 inches from a wall or Air Handling Unit. Do not mount under awnings or other projections within fifteen feet. Do not mount near economizers, intakes or exhaust fans, or barometric dampers. Do not mount within 10' of building corners or parapet walls.



*Figure 20 – Outdoor Static Pressure Sensor*

A detailed drawing of the outdoor static assembly is included within the package. Assemble mounting bracket and tubing per this drawing. 50' of 1/8" pressure tubing is supplied with the sensor.

1. Route the tubing such that it will not be subject to damage.
2. Do not directly attach the tube to surfaces that may become very cold such as suction lines or supply ducts as condensation may occur in the tubing.
3. It is recommended that all of the tubing length be used as this helps buffer any fluctuation in the sensor readings due to wind gusts.
4. Excess tubing should be coiled at some convenient location rather than cut.
5. Connect the tubing to the static pressure differential transducer in the unit.
6. The correct port is labeled for the outdoor air sensor.
7. Closely observe that the indoor static pressure sensor and outdoor static pressure sensor are installed on the proper ports as labeled.

#### **2.8.4 Installation of VOC Monitoring Sensor**

Desert Aire provides a Volatile Organic Compound (VOC) monitoring sensor that can trigger a greater flow rate of outdoor air when indoor contaminants reach a user determined concentration. A sensor will be provided in the unit or shipped loose for field installation depending on the configuration ordered.

##### **VOC Sensor in the Unit**

If ordered with Sensor in Unit the sensor is included downstream of the filter rack. The level of the VOC in parts per million will immediately be available when the controller is powered on. It should be noted that for reasonable accuracy that the fan should be constantly powered.

##### **VOC Sensor in Zone**

If ordered with Sensor in Zone the sensor is shipped loose for field mounting. This sensor should be mounted in a space that represents the typical breathing zone for the occupants or directly in the unit. The back mounting plate is suitable for mounting on a 2" x 4" J-Box or directly to drywall. Screws are provided.

Three wires are required and terminals on the sensor can accommodate 16 to 22 AWG. 18 AWG wire can be used up to 500 ft. run. Terminate wires as shown on the low voltage diagram.

Check to ensure that the sensor output has been set for 0-5 VDC output. The J3 jumper should be set in the storage position. See data sheet supplied with sensor for additional details.




Figure 21 – VOC Monitoring Sensor

## 2.9 Auxiliary Heating Control Wiring

Note: You must use the Desert Aire control system to control the interlock with the room heating system. This prevents wide fluctuations in room air temperature. It also prevents the heater from trying to heat the room while the dehumidifier is running in cooling.

Desert Aire will provide a signal to operate the auxiliary pool room heating system. The signal can either be a binary dry contact closure or a proportional voltage with an optional dry contact closure to operate an interlock or pump. The heating output type is pre-set from the factory based on the request at the time of order.

### 2.9.1 Auxiliary Heating – Dry Contact Closure

Desert Aire will provide a dry contact closure to interlock with the building heating system. This contact closure is normally used to interlock with a gas or electric duct heater which has its own power supply transformer. When the room air temperature drops below the set point, the dry contact will close to energize the auxiliary heater. See the dehumidifier wiring diagram for details.

### 2.9.2 Auxiliary Heating – Proportional Signal

Desert Aire will provide a proportional signal to modulate a heating coil control valve on units equipped with an integral heating coil.

This signal is reverse acting or direct acting depending on the settings in the controller. It is critical that units with hot water and steam coils be set properly for freeze protection. See CM3560 Series controller manual for details on the settings and outputs.

The SP dehumidifiers are equipped with a local man-machine interface on the face of the unit controller located inside the electrical box of the unit. A separate, optional remote display terminal can be ordered for service or remote access. See the CM3560 controller manual for details on wiring and environmental limits. A tag on the actuator cable identifies the electrical connections and the wiring details are also included on the actuator housing.

Most proportional valves have either three or four terminals for field-installed wiring.

- Four-terminal valves have two terminals for 24 VAC power and two terminals for the signal input.
- Three-terminal valves have one terminal for the “hot” 24 VAC input, a second terminal for the “positive” signal input, and a third, common terminal for the “neutral” 24 VAC input and the “negative” signal input.

You must follow the instructions included with the valve cut sheet. Observe the proper polarity, or you may damage both the valve and the Desert Aire controller. See the unit wiring schematics for information on signal wire connection points.

When the proportional signal is ordered, the binary heating output acts as an interlock. This can be used to activate a pump, valve, or interlock that needs to be coordinated with the proportional heating signal. The contact rating is shown on the electrical schematic. Use a transformer and relay to energize loads that are higher than the contact rated current draw or power.

## **2.10 Gas Heater (Optional)**

### **2.10.1 Gas Heater Installation Safety**

The Desert Aire dehumidifier may be equipped with an optional Category III gas-fired heater to provide air heating during the winter months. You must read and understand the following guidelines and warnings before you connect the heating section. Failure to follow these guidelines can result in improper and unsafe operation of this equipment, which can cause severe personal injury, death, or substantial property damage.

Observe the following precautions:

- Follow all appropriate national and local code and guidelines when installing gas-heating equipment. Failure to follow CGA, NFPA, and/or ANSI standards may cause equipment damage, personal injury, or death.
- Corrosive environments may reduce heater service life. This furnace is not to be used for temporary heating of buildings or structure under construction. Many of the chemicals used during construction form acid-bearing condensate when burned. This can substantially reduce the life of the heat exchanger.

- Gas heating equipment located indoors requires adequate combustion air. If you install the equipment inside a penthouse or mechanical room, an indoor unit heater and terminal kit must be used.
- Connect this furnace to an approved vent system only. Combustion products must be vented outdoors.
- Use a soap-bubble solution or an electronic detector to check for gas leaks. Never use a lighter or open flame to find leaks.
- The return air duct of the furnace must be sealed air tight to prevent starvation of the combustion air, especially if the furnace is located in a closet or confined area.
- Because of the potential of odorant fade, a gas leak may not be detected by smell. If this equipment is installed below grade, contact your gas supplier for a gas detector.
- Maximum gross stack temperature must not exceed 480°F (249°C) under any circumstances.
- Care must be taken not to wet electronic components during leak test. Wetting the electronic components may damage circuitry and cause a hazardous situation. Dry moisture from all leads and terminals if minor wetting occurs. Wait at least 24 hours for the circuit to fully dry before energizing the burner circuit.
- The gas burner and its individual gas shutoff valve must be disconnected from the gas supply during pressure testing of the gas supply system at pressures in excess of 0.5 psig (14.0" w.c.).
- Copper and brass tubing and fittings (except tin lined) shall not be used if the gas contains more than a trace (0.3 grains per 100 cubic ft.) of hydrogen sulfide gas. Check with your gas supplier.
- For initial start-up of the furnace after installation, it may be necessary to purge the air out of the gas line. This should be done by a qualified heating contractor. If excessive gas escapes when purging the gas supply at the union, allow the area to ventilate for at least 15 minutes before attempting to start the furnace. LP gas is especially dangerous because it is heavier than air and may accumulate to a dangerous concentration at the floor level.

### **2.10.2 Gas Piping**

Gas supply piping installation should conform with good practice and to national and local codes. The orifice for the burners are sized for either natural gas (having a heating value of 1025 BTU per cubic foot and a specific gravity of 0.60) or for liquefied propane gas (with a heating value of 2500 BTU per cubic foot and a specific gravity of 1.53). If the gas at the installation does not meet this specification, consult the factory for proper orifice sizing.

## **Seal the opening for the gas supply pipe with the grommet provided**

Supply lines must be sized based on pressure drop and capacity. Gas piping must be large enough to provide adequate gas with minimal pressure drop. Use the table below as a guide to capacity. Note that each gas heat module in a SelectAire Plus™ unit will have an independent connection. Ensure that any branch connection is also properly sized for a minimal pressure drop. Gas piping must conform to all applicable codes and standards. Follow standard gas piping practices, including:

- Pitch gas piping downward in the direct of flow so condensed moisture can drain freely.
- Install a drip leg at the lowest point in the gas line to prevent moisture and debris from clogging the gas drain. The National Fuel Gas Code requires the installation of a trap with a minimum of 3" drip leg. Local codes may require a longer drip leg, typically 6".
- Install a ground joint union and manual shutoff valve in an accessible position close to the equipment.
- Ensure that the pipe and fittings are free from chips and debris. Make sure that the threads are clean and properly cut.
- Seal pipe threads with pipe dope or a suitable joint compound that is compatible with the gas you are using. Do not use Teflon tape to seal gas pipe joints.
- Support gas piping using suitable straps or hangers to avoid stressing the gas valve or manifold.
- Use a backup wrench when you tighten gas pipe and fittings.
- Piping from the natural gas meter to the furnace shall be in accordance with requirements of the local utility. Piping from the LP tank to the furnace must follow the recommendations of the gas supplier.
- A readily accessible, certified manual shut off valve with a non-displaceable rotor member should be installed within six feet of the gas equipment it serves.
- A union or flanged connection shall be provided downstream from the manual valve to permit removal of controls. Provide a 1/8" N.P.T. plugged tapping at the inlet of the gas control for connection of a test gauge to check gas supply pressure to the furnace. Unions must be a ground joint type or flagged-jointed using a gasket resistance to LP gas. Pipe dope or sealant certified to be resistant to the action of liquefied petroleum gases should be used on all threaded joints.

- A drip leg must be used on both LP and natural gas installations prior to the furnace to trap oil, condensate and other impurities which might otherwise lodge in the gas valve or plug the burner orifice. When there is excessive condensation between the gas meter and the furnace, a drip leg shall be provided at the outlet of the gas meter. Failure to install a drip leg may void the warranty on the dehumidifier.
- High fire manifold gas pressure is regulated by the combination valve to 3.5" w.c. Inlet pressure to the valve must be a minimum 5" w.c. or as noted on the rating plate and maximum of 14" w.c. for natural gas.
- **Note:** Always check the rating plate for minimum gas supply pressure. Minimum supply pressure requirements vary based on size and burner and gas control option.
- LP Only: Experience has proved that the pressure drop in the gas line running from the outside propane gas tank to the gas appliances inside is the most frequent cause of equipment malfunctions. A single pressure regulator, located at the tank, will not reliably regulate the high tank pressures (up to 200 psi) down to 11" w.c. Varying pressure will occur at the appliances as outside temperatures and usage demands vary. Two-stage regulation is the only effective method of controlling these variables.

Capacity of Piping						
Cubic Feet per Hour based on 0.3" w.c. Pressure Drop						
Specific Gravity for Natural Gas – 0.6 (Natural Gas – 1000 BTU/Cubic Ft.)						
Specific Gravity for Propane Gas – 1.6 (Propane Gas – 2250 BTU/Cubic Ft.)						
Length of Pipe	Diameter of Piping					
	1/2"		3/4"		1"	
	Natural	Propane	Natural	Propane	Natural	Propane
20'	92	56	190	116	350	214
30'	73	45	152	93	285	174
40'	63	38	130	79	245	149
50'	56	34	115	70	215	131
60'	50	31	105	64	195	119
70'	46	28	96	59	180	110
80'	43	26	90	55	170	104
90'	40	24	84	51	160	98
100'	38	23	79	48	150	92
125'	34	21	72	44	130	79
150'	31	19	64	39	120	73
175'	28	17	59	36	110	67
200'	26	16	55	34	100	61
Length of Pipe	Diameter of Piping					
	1-1/4"		1-1/2"		2"	
	Natural	Propane	Natural	Propane	Natural	Propane
20'	730	445	1100	671	2100	1281
30'	590	360	890	543	1650	1007
40'	500	305	760	464	1450	885
50'	440	268	670	409	1270	775
60'	400	244	610	372	1105	674

Figure 22 – Gas Pipe Capacities in Cubic Feet per Hour






Figure 23 – LP 2-Stage LP Gas Piping

**LP Only:** Use the following line size chart to size the gas piping or tubing between the LP tank and the second-stage regulator:

Section 1						Section 2						
	If the length of line between regulators (tank to building) is this long.						If the length of line between second-stage regulator and furnace is this long.					
Use this size tubing to keep pressure drop below 2 lbs. for maximum flow shown.	Total input load (Btu/h) on line	25'	50'	75'	100'	Use this size tubing or pipe to keep pressure drop below 1/2" water column for maximum flow shown.	Total input load (Btu/h) on line	10'	20'	30'	40'	50'
	125,000	3/8" O. D. Copper					75,000	5/8" O. D. Copper				
	250,000	3/8" O. D. Copper		1/2" O. D. Copper			125,000	5/8" O. D. Copper		3/4" Black Pipe		
	375,000	1/2" O. D. Copper					187,500	3/4" Black Pipe				
	500,000	1/2" O. D. Copper					250,000	3/4" Black Pipe				
							375,000	3/4" Black Pipe		1" Black Pipe		
						500,000	1" Black Pipe					

Figure 24 – LP Gas Pipe Sizing Information

**LP Only:** Seamless copper tubing may only be used with gases that are not corrosive to it. Copper tubing or tubing with internal copper surfaces, when used for conveying gas, shall be internally tinned or equivalently treated to resist sulphur corrosion. See the note below to check with your LP gas supplier before using copper. Seamless copper tubing must comply with standard type K or L for seamless copper water tube, ASTM B 88; or seamless copper tube for air conditioning field service, ASTM B280.

**LP Only:** Copper and brass tubing and fittings (except tin lined) shall not be used if gas contains more than a trace (0.3 grains per cubic ft.) of hydrogen sulfide gas. Check with your gas supplier.

**LP Only:** Maximum supply pressure for liquefied petroleum (LP) gas is 13.5" w.c. and minimum supply for purpose of input adjustment is 11" w.c.

Before attempting to measure or adjust high fire manifold gas pressure, the inlet (supply) pressure must be within the specified range for the gas being both used when the heater is in operation and on standby.

Incorrect inlet pressure could cause excessive manifold gas pressure immediately or at some future time. With the manual valve, on the combination valve, positioned to prevent flow to the main burners, connect a manometer to the 1/8" pipe outlet pressure tap on the valve. Open the valve and operate the heater to measure the manifold gas pressure.

**Note:** A manometer (fluid filled gauge) is recommended rather than a spring type gauge due to the difficulty of maintaining calibration of a spring type gauge. Normally adjustments should not be necessary to the factory preset regulator. If adjustment is necessary, set pressures to above settings by turning regulator screw in (clockwise) to increase pressure. Turn regulator screw out (counter clockwise) to decrease pressure. Consult the valve manufacturer's literature provided with the heater for more detailed information.

### 2.10.3 Gas Heater Location

The following items must be considered when choosing the size and location of the furnace. Note that dehumidifiers designed for outdoor use are already equipped with combustion air intakes and venting means. Field-installed venting is only required on indoor dehumidifiers.

All local codes and/or regulations take precedence over the instructions in this manual and should be followed accordingly. In the absence of local codes, installation must conform to these instructions, regulations of the National Fire Protection Association, provisions of National Electrical Code (ANSI/NFPA70 latest edition), and the National Fuel Gas Code (ANSI Z223.1 latest edition).

- **Indoor units only:** The dehumidifier should be located as near the vent terminal as practical to minimize the numbers of elbows and the length of any horizontal run of connecting flue pipe which may be required.
- Definitions of "combustible material" and "non-combustible material" as issued by ANSI Z223.1 are as follows:
  - **Combustible Material:** Material made of or surfaced with wood, compressed paper, plant fibers, plastics or other material that will ignite and burn whether flameproof or not or whether plastered or not.
  - **Non-Combustible Material:** Material which will not ignite and burn; such materials consisting entirely of steel, iron, brick, concrete, slate, glass, plaster, or combination thereof.

- Indoor units only: The dehumidifier must be located on a level, dry surface in an area which is free from and protected from excessive drafts or wind. It must be installed so that the electrical components are protected from water. If the area becomes wet or damp at times, the dehumidifier should be raised above the floor using concrete blocks or steel dunnage.

Measures should be taken to prevent the entry of corrosive chemicals or vapors to the combustion and ventilation air supply. Such chemicals include but are not limited to chlorinated and/or fluorinated hydrocarbons such as found in refrigerants, aerosol propellants, dry cleaning fluids, degreasers, and removers. Other harmful compounds may come from bleaches, air fresheners or mastics. Vapors from such products can form acid compounds when burned in a gas flame. Should acid compounds form in your furnace; it may reduce the life of the furnace. Please follow these guidelines for providing outside air directly to the appliance to avoid this problem.

The return air duct of the dehumidifier must be sealed air tight to prevent starvation of the combustion air, especially if the burner is located in a confined area.

All indoor separated combustion, power vented units **MUST BE** equipped with both combustion air and exhaust piping to the outdoors. Since the design of the system will be unique to each job site, this must be properly completed by the design professional responsible for the overall mechanical system design.

**Hazards of Chlorine** – The presence of chlorine vapors in the combustion air of gasfired heating equipment presents a potential corrosive hazard. Chlorine, found usually in the form of Freon or degreaser vapors, when exposed to flame, will precipitate from the compound, and go into solution with any condensation that is present in the heat exchanger or associated parts.

The result is hydrochloric acid which readily attacks all metal including 300 grade stainless steel. Care should be taken to separate these vapors from the combustion process. This may be done by wise location of unit vent terminal and combustion air inlet with regard to exhausters or prevailing wind directions. Remember, chlorine is heavier than air. This fact should be kept in mind when determining installation location of these heaters and building exhaust systems.

## **WARNING**

**Desert Aire units are not designed or approved for use in atmospheres containing flammable vapors or atmospheres highly laden with chlorinated vapors.**

The following requirements must be followed when connecting this furnace to a vent system.

- The connection of this burner to the vent system shall be in accordance with the local building codes, the vent manufacturer's instructions and Part 7, venting of equipment, of the National Fuel Gas Code, ANSI Z223.1
- You must tightly seat all joints of the vent. The inside of the vent should be free of all obstructions.
- All vents and vent connections must fit tightly to avoid air leaks.
- All vent connectors connecting the furnace to the vent must be rigidly supported with hangers and straps, in order to prevent sagging and movement after installation. The vent connector must be supported every four feet for the design and weight of the material used, to maintain clearances, and to prevent physical damage. The vent pipe must slope upward 1/4" minimum for each foot of horizontal run away from the furnace.
- Vent connectors used in connecting the furnace to the vent cannot be channeled through floors, ceilings, and walls without the proper protective construction. This construction must be in accordance with the requirements of the National Fuel Gas Code (ANSI Z223.1 latest edition).
- The venting system must be installed to avoid possible contact with concealed plumbing or electrical wiring.
- In addition to following the requirements outlined by local codes, follow the guidelines below when locating the vent terminal to help ensure trouble-free operation of your horizontally vented burner.
- Avoid locating the vent terminal on a wall facing the prevailing winds or wide open areas. When this is not practical, choose locations that protect the vent from strong wind, such as behind a fence or hedge. (Note: the vent terminal must be located a sufficient distance from bushes, shrubs and vegetation so as not to have the flue products restricted or blocked by such vegetation.).
- In areas with considerable snowfall, locate the vent terminal higher than the recommended minimum 12 inches above the ground as protection from blockage by snow accumulation or drifting.
- Locating the vent terminal as close as possible to the outside corner of a building rather than centered on an open wall will also minimize the effect of direct winds. Avoid alcoves and similar areas that may increase wind loading of the vent termination.
- The gas venting system should be inspected prior to the heating season by a qualified technician. This inspection should include removal of the cap to confirm an unrestricted vent.

Follow these steps outlined in the National Fuel Gas Code, NFPA 54/ANSI Z223.1 –latest edition to resize the vent system to approach the minimum size using the appropriate tables in the Appendix of that code. The National Fuel Gas Code may be obtained by writing to:

American Gas Association Laboratories  
8501 East Pleasant Valley Road  
Cleveland, OH 44131

or

National Fire Protection Associate  
Batterymarch Park  
Quincy, PA 02269

Refer to the documents located in the heater module for more detail instructions on installation on your specific terminal unit.

## 2.10.4 Gas Furnace Venting

For outdoor units, connect supplied B-type vent to flue gas pipe.

### 2.10.4.1 B-Vent Parts

See Figures 25a, 25b, 25c, and 25d below for an image and description of included B-vent assembly parts.



Figure 25a – 12" Vent Cap



Figure 25b – B-Vent



Figure 25c – Tall Code Flashing



Figure 25d – Storm Collar


### 2.10.4.2 B-Vent Assembly Instructions

Use gloves when handling vent parts.

- To assemble joints of pipes and fittings, first make sure that the lock ring is moved upward sufficiently to clear the formed tabs. Check the tabs to see that they are projecting slightly outward from the pipe so that the upper section will slide down over the end of the lower section to which it is being

joined. Look up the word “UP” with the arrow pointing in the direction of the flu-gas flow.

- Slide the top pipe or fitting down over the upper end of the pipe or fitting until the projections on the tabs line up with the groove in the draft hood pipe. The joint will naturally come to a stop at this point if it is placed firmly down over the pipe or fitting.
- Using your thumbs and fingers press the tabs into position and slide the lock ring down to lock the tabs in place.
- Use the above instruction steps to attach the B-vent directly to the draft hood (see Figure 26) of the gas heater.
- The roof flashing (Figure 25c) (C in Figure 25) should be placed down over the upper end of the B-vent pipe (Figure 25b) (B in Figure 26) and adjust so the base plate of the flashing fits tightly against the roof with the vent pipe held in position. Seal the inner edge with sealant against the pipe. The flashing should be sealed to the roof.
- Use weather strips to seal the pipe above the flashing.
- The storm collar (Figure 25d) (D in Figure 25) must be placed immediately above the roof flashing and sealed with roof cement or RTV silicone to seal the joint between the storm collar and the vent pipe.
- Next install the vent cap (Figure 25a) (A in Figure 26). The cap has a spring clip which engages and locks automatically when the cap is pushed onto the pipe.



*Figure 26 – B-Vent Fully Assembled*

### 2.10.5 Indoor Unit Set-up Instructions

For indoor units, follow heater manufacturer instructions for discharge gas vent piping.

### 2.10.6 Finalize Installation

Connect communication and power wiring from the unit to the heater. Be sure to keep conduit clear of door openings. Connect to 2" NPT gas lines per heater manufacturer instructions. Connect to 1" CPVC condensate drain connection per heater. See Figures 26a and 26b.

### 2.10.7 Gas Heater Start-Up

Place the unit into heating mode. Verify the induction fan begins running. Verify the switch on the top of the controller is switched to "ON" (not "TEST"). Allow the unit to reach steady state. Use a flue gas analyzer in the Flue gas duct and document: O<sub>2</sub> (%), CO (PPM), Efficiency (%), CO<sub>2</sub> (%) and gas temperature.




Figure 27a – (Top) Final Single B-Vent Installation and Figure 27b – (Bottom) Final Dual B-Vent Installation

### 2.10.8 Gas Heater Condensate Drain

When the SelectAire Plus™ unit is provided with a gas heater, trap the condensate connections as shown in Figure 28. Traps for each heater section must be trapped independently. The condensate drain may be constructed with Schedule 40 PVC pipe, fittings and components. All joints must be watertight to prevent leakage. Installation of a union ahead of the trap is preferred to permit maintenance of drains and accommodate service and maintenance of the condensing furnace or you may install a cleanout tee or plug near the trap.

A minimal amount of static is generated. Ensure that the outlet of the trap is lower than the inlet and the bottom of the trap is at least 2" lower than the outlet. Waterless traps are an acceptable substitute.




Figure 28 – Gas Heat Sectional View of Condensate Trap Requirements

Traps are installed to keep an air gap in-between the flue gases, condensate generated during combustion, and the building drain. Improper installation or application of the traps can lead to poor combustion (excessive amounts of CO) and/or cause the heating unit to not operate.

Where condensate drains are located outside of a heated space and temperatures will fall below freezing, the entire drain line and trap must be thermally protected. Use a 2.5 to 5 watt per foot at 115VAC, 40°F self-regulating, shielded and waterproof heat tape. A receptacle has been provided in the heating vestibule for this purpose.

Condensate drain lines must always be sloped toward the discharge for proper condensate removal. For installation where the building drain lines are above the level of the duct furnace drain system, a condensate pump may be required. Note that the products of combustion can be highly corrosive. Ensure that the condensate pump is rated for gas heat flue condensation.



### **2.10.9 Induced Draft Fan**

An induced draft fan or combustion air blower are products which incorporate an integral fan or blower as part of the heater assembly to provide metered air for the combustion process.

Even with these fans in place, certain applications such as horizontal side wall venting are limited in the length of vent piping that can be applied due to pressure drop in the vent. HDA series furnaces are limited to a maximum vent length of 50 lineal feet of 6" diameter pipe. Depending on the pipe diameter, fittings need to be included in determining the total lineal feet. Depending on heater location, routing of the vent pipe and other requirements, vent piping may exceed the maximum vent length listed for the product.

In these cases, a vent booster fan (also referred to as a power venter) may be applied to the vent system to overcome the additional pressure loss and insure products of combustion are properly exhausted.

Precision Vent, and other vent system manufacturers, provide venting solutions for indoor gas heater installations. These systems typically include a booster fan (power venter).

Precision Vent can be contacted at:  
829 Pickens Industrial Drive, Suite 5  
Marietta, GA 30062  
Tel: 678-213-1332

### **2.11 Auxiliary Pool Water Heating**

A properly sized Desert Aire dehumidifier equipped with the pool water heating option can maintain the pool water temperature under normal conditions. However, like any refrigerated dehumidifier, the Desert Aire unit may require days to heat a recently-filled pool by itself. For this reason, you should install an auxiliary pool heater.

Desert Aire dehumidifiers ordered with the water heating option are provided with a set of dry contacts for controlling an auxiliary pool water heater. The dehumidifier will be the primary source of water heating. If it cannot keep up with the demand for pool heat, the Desert Aire controller will then energize the auxiliary water heater.

**Note:** Do not use the aqua stat mounted on the auxiliary heater for temperature control. This can lead to excessive water temperature fluctuation. It may also permanently prevent the dehumidifier from heating pool water if the set point of the heater aqua stat is higher than the water heating set point of the dehumidifier.

### **2.12 Smoke Alarm Interlock**

Desert Aire SP series dehumidifiers are equipped with a set of terminal blocks for interlocking with the smoke alarm (alarm provided and installed by others). The smoke alarm contacts must be rated for at least 15 amps at 24 VAC. The contacts must break when smoke is present. This will shut off the blower(s) and compressors.

See the dehumidifier wiring diagram for connection details.

## 2.13 Auxiliary Air Heater – Hot Water Coils

### Initial Fluid Start-Up Prep

- Open all vents so that air is eliminated from within the coil circuitry and headers. Verify that all vents and drains are not obstructed and do discharge a stream of water.
- Fill the coil with water (or glycol mix) then close all vents.
- Perform an initial hydrostatic leak test of all brazed, threaded or flanged joints, valves and interconnecting piping. Recheck the coil level and correct if necessary. When the setup is found to be leak free, discharge and discard initial water charge. It is important that all grease, oil, flux and sealing compounds present from the installation are removed.

### General

- Proper air distribution is vital to coil performance. Air flow anywhere on the coil face should not vary by more than 20%.
- The drain pan and associated piping (drain line and trap) should be installed so that there is no standing water in the drain pan and that no blow-through occurs.
- Fluid and air velocities should be maintained within our recommended values.

% Ethylene Glycol by Volume	Freeze Point	% Propylene Glycol by Volume	Freeze Point
0	32°F	0	32°F
10	25°F	10	26°F
20	16°F	20	19°F
30	3°F	30	8°F
40	-13°F	40	-7°F
50	-34°F	50	-28°F
60	-55°F	60	-55°F

Figure 29 – Freeze Points (may vary from product to product)

## 2.14 Packaged Condenser Hail Guard and Pre-Filter Assembly Instructions

If your SP is a packaged unit, Hail Guard and Pre-Filters will be assembled over the packaged condenser coils.

### 2.14.1 Packaged Condenser Hail Guard

Hail Guard netting and a pre-filter will arrive mounted to the surface of the packaged condenser units. The guard netting will be attached with tek screw and neoprene lined washers. A frame for the pre-filters will be installed over the netting. If servicing the hail guard, the frame must be removed first. When reinstalling the hail guard, align the hail guard grommets over the holes and screw the tek screws into the cabinet. The condenser coils are not the same size so be sure to use the correct guard with each condenser coil.




Figure 30 – Hail Guard Final Assembly

### 2.14.2 Packaged Condenser Pre-Filters

On Packaged units, pre-filters will be installed over the netting on all packaged condenser units. The A circuit and B circuit coils are not the same size so take care to assemble the correct pre-filter to the unit.

#### 2.14.2.1 Mounting

The pre-filters are installed over the hail guard netting with a retainer assembly. This is a three-piece assembly. A 1/4 turn bail handle fastener will slide into the front of the pre-filter grommet. Next, a retainer will slide on the backside of the pre-filter onto the fastener to secure the fastener to the pre-filter. Finally, the fastener will slide into a receptacle that is mounted to the back of the pre-filter frame on the unit. See Figure 31.



Figure 31 – 1/4 Turn Fastener, Retainer, Receptacle For Pre-filter Assembly

#### 2.14.2.2 Inspection

Pre-filters are intended to become part of your normal maintenance program. Visual inspection for debris build up on the pre-filters should be completed at a minimum of every 4 months or sooner depending on the application, the environment and the use of the equipment.

#### 2.14.2.3 Cleaning

Pre-filters may be cleaned in a variety of ways, including:

- Brushing / broom cleaning (in place on equipment or removed)
- Vacuuming (in place on equipment or removed)

- Hose cleaning with or without detergents and rinsed thoroughly by hosing from the reverse side (removed).

## 2.15 Section Cabinet Assembly Instructions (Optional)

If the unit has been designed for a sectioned unit installation, please follow the instructions below in addition to the standard installation instructions included within the unit. Assembly components will be shipped in a section. Take care not to lose these components. They will be used to finalize assembly of the system. See Figure 32 below as an example of the items that may be included in a section of the system.




Figure 32 – Cabinet Gasket Location

### 2.15.1 Rigging Instructions

- Refer to the installation instructions included with the unit for lifting procedure.
- In addition, unit sections must be properly braced to ensure safe lifting without damage to the unit.
- The unit is NOT designed to be assembled and lifted as a single unit. Lifting unit as a single piece may damage the cabinet, internal machinery, and endanger personnel.
- Lifting lug angle brackets located at each base corner or unit splits have a series of smaller holes to accommodate bolts for pulling and securing sections together and a larger hole to assist in lifting and/or maneuvering the unit sections.

### 2.15.2 Cabinet Assembly

- Gasket material is pre-installed at the section borders. This material should remain attached to the cabinet during the assembly process as it is important for sealing and separating the sections. See Figure 33.




Figure 33 – Cabinet Gasket Location

- Alignment of the sectioned units is critical for the proper assembly of the SP system. To properly align the cabinet sections. Start with all sections on the same flat surface. 2x4's or similar may be used to facilitate this alignment (refer to Figure 34). Units with three or more sections will have letter labels at the adjoining sections. These labels are placed at the bottom of each section such as A-A, B-B, C-C, etc. to ensure proper mating of sections (refer to Figure 34).




Figure 34a – Cabinet Alignment

- Units with refrigeration circuit splits have varying amounts of refrigeration reconnections required depending on the unit size and configurations. Inspect the unit and identify all refrigeration breaks. There will be a service valve on either side of the joint to be connected.
- Clean the pipe stubs and coupling surfaces. When sliding the sections together align the coupling on one side of the connection to the corresponding pipe stub on the other side. Follow the procedures in *Section 2.15.3* for refrigeration piping assembly.
- When pulling sections together that contain refrigeration splits (if applicable), verify all the refrigeration couplings are aligned to the mating refrigeration tube in the adjacent section.
- Constantly finesse each connection to assure tubing connections are not binding up while slowly moving the sections together until the sections have been secured.

- At each seam place the Joining Plate between each sections lifting lugs. Insert two bolts through section lifting lug, joining plate, and then through the next section lifting lug as shown in Figure 34b. Tighten the nut to ensure that both sections are securely fastened together at the base.




Figure 34b – Cabinet Identifier, Vertical and Base Rail Fastening

- After the cabinet sections are pushed together vertical panel mounting strips and mounting tape will be used to seal and bond the sections together. These should be secured after the base lifting lug angle brackets have been secured. Apply the provided mounting tape to the seam of both mating cabinet sections (see Figure 34b). Align the provided mounting strips with each section edge and apply pressure to secure the strips to the cabinet sections. Use provided drive #8 screws through all holes in each mounting strip. Repeat the above steps to install the top mounting strip sections (see Figure 34d).




Figure 34c – Side Cabinet Fastening




Figure 34d – Top Cabinet Fastening

- Internal cabinet mounting brackets may also be included (see Figure 34e). After the above steps are complete use tek screws to mount the other side of the bracket to the adjacent section. This will aid in alignment and structure of the assembled cabinet sections.




Figure 34e – Internal Cabinet Fastening

### 2.15.3 Refrigeration Piping Reassembly (when applicable)

Piping sections will be made accessible at either the edges of the cabinet sections or through doors. The images below will provide an example of what the refrigeration piping assembly will look like after installation. Due to a broad array of SP selection options your unit may look different the assembly pictured below. The pictures below are an example that may provide assembly context for sectioned SP units.

Connections may be capped and/or contain an isolation valve. Do not open the valves until all refrigerant piping is completely installed as it may stop the refrigerant charge from escaping. See Figure 36.




Figure 34 – Section Edge Location




Figure 35 – Piping Location




Figure 36 – Tube Locations in Cabinet

Below are a few images of connection locations. The sections will be pushed together in the directions of the arrows.





*Figure 37 – Piping Location*

There will be copper tubing segments with couplings that are pre-installed to each segment in the Cabinet Reassembly section. These couplings will be used on one side of the splits when able. Slide coupling over the mating pipe stub and braze the pipe stub to the coupling.

A plate partition may also be included. If included, slide the plate partition over the tubes then complete the brazing process to the tubes as detailed below.



*Figure 38 – Refrigerant Tube Partition Plate*

To properly braze these sections:

- Remove grease or oil first using a dry towel and solvent sprayed onto the towel if necessary.
- Remove dirt and oxidation using a Scotch-Brite pad, tube brush, or a wire wheel. Clean the tube end to a depth about 1/2" greater than the insertion depth of the tube.
- Flow nitrogen through the braze assembly during brazing to eliminate the formation of oxides inside the tubing. The presence of oxygen creates when exposed to brazing temperatures. Flowing nitrogen through assemblies displaces oxygen which keeps internal surfaces oxide-free.
- There should be one inlet and one outlet when flowing nitrogen through an assembly.

- Adapt the nitrogen hose to the inlet side of the assembly. The adapter should seal the inlet opening tightly.
- Verify nitrogen flows through all parts of the assembly being brazed.
- Set nitrogen flow to about 15 scfh (standard cubic feet / hour). Braze the line connections together with Sil-Phos 5 brazing alloy once fittings and copper tubing has been set in place.
- Wrap critical components such as valves with a cool, damp rag to reduce possibilities of heat damage.
- Braze the line connections together with Sil-Phos 5 brazing alloy once fittings and copper tubing has been set in place.
- Using a cool, damp rag, wipe the outside of the joint taking care not to get water inside the assembly. Continue cooling until assembly is cool enough to touch.
- Wipe off all flux residue.
- Once braze joint is cooled down nitrogen may be removed.
- Cap all open parts of the assembly or circuit.

#### 2.15.4 Drain Piping Reassembly (when applicable)

Drain connections will need to be reassembled as well. There will be pvc tubing segments with couplings that are pre-installed to each segment in the Cabinet Reassembly section. Couplings will be used on one side of the splits when able. Slide coupling over mating tube and properly prime and glue with PVC cement. Below shows an example of how this may look. Note the extension tube that was included in this example.




Figure 39 – Drain Tube Connections

#### 2.15.5 Refrigeration System Evacuation / Preparation for Operation (when applicable)

- Pressure test each reconnected refrigeration lines to insure leak-tight connections.
  - Install a pressure gauge on the system or downstream of the regulator valve on a tank of nitrogen.
  - Let system sit for 10 minutes. Ensure that pressure has not decreased after this time.
  - Relieve the pressure.
- Evacuate the section of tubing between the ball valves on each reconnected refrigeration line splice.
  - Verify pressure is removed using Schrader core depressors.
  - Connect and turn on pump.

- The refrigeration system must stay below 500 microns after 10 minutes of decay testing. The recommended starting point to pass the decay test is around 350 microns.
- After successful leak testing and evacuation, open all ball valves interconnecting the unit sections.

### 2.15.6 Electrical Wiring / Airflow Tubing Assembly

- Wiring junction boxes and mating wiring harnesses will be labeled using the format of A-1, A-2, B-1, B-2, etc. Where the letter identifies the section split and the number the individual box and connecting wiring harness in this section.
- All wiring harnesses are disconnected from the electrical panel and rolled up, tagged and secured in the section for the component to allow easy reconnection into the electrical panel.
- Line power cables will need to be reconnected to blower motor(s) and compressor(s) where applicable.
  - Cable will be identified by the component number it connects to on the wiring schematic. (e.g. M310, FU110)
  - Some wires from harnesses will be wired to the “High Voltage Field Connections” terminal block as shown in Figure 40. Connect to the corresponding terminal block ID #.
- Control voltage cables will be tagged and need to be reconnected to their respective terminal blocks for compressor control, refrigeration controls, damper actuators, valves, etc.
  - Connect cable to the corresponding multi-tier terminal block as shown in Figure 40. (e.g. SOL217)
  - Connect wires to corresponding color on the terminal block. As an example, red wires connect to “RED” connection. Note: Green wires terminate at either the “GREEN” marker or “GND” for grounding purposes.
  - Insure all wiring is clamped in place once reconnections are made.




Figure 40 – Terminal Blocks

### 2.15.7 Reconnect Differential Pressure Tubing (if applicable)

- Route coiled sections of clear 3/16" tubing into electrical enclosure making sure not to kink or crush tubing.
- Connect corresponding tube numbers to barbed tube connections in the main electrical enclosure as shown in Figure 41.




Figure 41 - Differential Pressure Tubing

## 2.16 Hood Assembly Instructions (if applicable)

### 2.16.1 Outdoor Air Hood Assembly (if applicable)

When an outdoor unit is supplied, the OA Air hood will arrive assembled to the cabinet.

### 2.16.2 Exhaust Hood Assembly Instructions

Units configured to be installed outdoors are provided with an exhaust hood. The hood is typically shipped in the same freight shipment as the dehumidifier.

#### 2.16.2.1 Standard Exhaust Hood Option

Connect the supplied exhaust hood to the cabinet. Here are instructions and images to set up the exhaust hood. Below are lists of the necessary tools and parts required for performing the installation.

1. Align the mounting rail with the existing cabinet holes.
2. With the 1/4" bit installed in the power driver insert the 13 screws through the mounting rail and into the cabinet per Figure 42a.
3. Apply sealant to the mating surfaces behind the exhaust hood.
4. Hang the hood on the mounting rail per Figure 42b.
5. Align the exhaust hood with the existing holes.
6. With the 1/4" bit installed in the power driver insert the 36 screws through the exhaust hood holes and into the cabinet per Figure 42c.

#### Tools Required (Not Included)

Power Driver  
1/4" Driver Bit  
Work Gloves  
Safety Glasses

#### Include Parts

#8 – 18 x 1/2" SS Screws (x49)  
Mounting Rail  
Exhaust Hood




Figure 42a – Mounting Rail




Figure 42b – Hood / Rail Assembly




Figure 42c – Hood / Rail Assembly

### 2.16.2.2 Right or Left Exhaust Hood Option

This hood is available as an option only. To install connect the supplied exhaust hood to the cabinet per the following instructions. Below are lists of the necessary tools and parts required for performing the installation.

1. Align the exhaust hood with the existing holes and support in place.
2. With the 1/4" bit installed in the power driver insert the 25 screws to the cabinet through the cover plate.
3. Finalize the installation of the exhaust hood by securing the hatch to the exhaust hood.

#### **Tools Required (Not Included)**

Power Driver  
1/4" Driver Bit  
Work Gloves  
Safety Glasses

#### **Include Parts**

#8 – 18 x 1/2" SS Screws (x25)  
Exhaust Hood  
Cover Plate




Figure 43a – Mounting Rail




Figure 43b – Hood / Rail Assembly




Figure 43c – Hood / Rail Assembly

## 2.17 Combination Moisture and Liquid Indicator

The moisture and liquid indicator combines the two functions of moisture and liquid indication into a single indicator. Excessive moisture in refrigerant systems can cause unwanted chemistries such as hydrolysis of lubricants and other materials, corrosion of metals, copper plating, and ice formation at the meeting device.

The indicator is a porous filter paper impregnated with a chemical salt that is sensitive to moisture. The salt changes color according to the moisture content (relative saturation) in the refrigerant. A dark green color indicates the refrigerant is DRY and yellow indicates a WET condition. The indicator is formulated so that it changes color as the moisture levels generally accepted as the safe operating range. The colors indicate the following moisture content in PPM:

- Dark Green → Less than 75 PPM
- Chartreuse → 75 - 150 PPM
- Yellow → Over 150 PPM

Change the drier when the color is in the caution or wet range. The action of the indicator element is completely reversible and will change color whenever the moisture content of the system changes. The indicating element may change color rapidly on some installations, while others may take a much longer period of time. New systems or systems where the drier has been replaced will cause the indicator to start changing color almost immediately. However, it is recommended that the equipment operate for 12 hours to allow the system to reach equilibrium before deciding if the drier should be changed.

The drying of the system should be continued until the indicating element stays Dark Green.

Additional Considerations:

- Bubbles: The Moisture and Liquid Indicator may be installed anywhere in the liquid line. When located between the Filter-Drier and the expansion device, bubbles indicate a shortage of refrigerant or a restriction in the liquid line such as a plugged drier.



- Oil: When a system is circulating an excessive amount of oil, the See-All indicator paper may become saturated. This causes the indicator to appear brown or translucent and lose its ability to change color, but does not permanently damage the See-All. Let the See-All remain in the system. The circulating refrigerant will remove the excess oil, and the indicator element will return to its proper color.

## **2.18 Crankcase Heaters, Heat Tape, GFI Outlets and Lighting**

### **2.18.1 Crankcase Heaters and Heat Tape**

The power source to the SP unit should be installed and energized for a minimum of 24 hours before starting the compressors. This allows the heaters to properly heat the compressor, water and condensate lines to warm to the required temperature for operation. Heat tape is used on condensate and waterlines in outdoor applications.

### **2.18.2 GFI Outlets and Lights**

There are two configurations for the installation of GFI Outlets. Either the GFI outlet receptacles will be powered by a dedicated 120V circuit or powered by the dehumidifier circuit (optional) using a dedicated transformer.

#### **2.18.2.1 Dedicated 120V AC Powered Lights, GFI, and Receptacle (Standard)**

In a standard configuration dehumidifier 120 VAC power will be supplied to the dehumidifier's panel by others. A separate terminal is available for this connection. It will be necessary to take precautions when powering up and when powering the unit down that the separate source must be considered.

#### **2.18.2.2 GFI and Lights Powered by the Dehumidifier (Optional)**

If your unit was ordered with the option to power the receptacles, lights and heat tape by the dehumidifier the main disconnect will turn the power on and off to both the primary circuit (i.e. 208/230V, 460V, or 575V) as well as to the 120 VAC circuit.

### **2.18.3 Receptacle for Gas Heat Trap Heat Tape (Outdoor Units Only)**

When an outdoor rated unit is equipped with the gas heating option, a receptacle is included in the gas heating section vestibule. This will allow for installation of customer supplied heat tracing on the condensate lines if necessary. The receptacle is on the same circuit as the GFI Outlet and lights. This receptacle is powered by a separate 120V field-supplied circuit, or optionally, an integral transformer. After connection has been completed, the power at this receptacle should be tested to ensure it is receiving power.

## **2.19 Vestibule Cabinet Vent Fans (Non-Packaged Units)**

Non-packaged units will include a refrigeration vestibule cabinet vent fan assembly. This assembly will keep the refrigeration vestibule cool when needed. Air is pulled from the bottom of the vestibule through an air return opening through the cabinet and exhausted out of the top of the cabinet with a vent fan. The vent fan forces air from inside the cabinet out to the area surrounding the SP unit, so



that a slight negative pressure is created inside the enclosure. The fan is controlled by a thermostat to ensure the proper vestibule temperature. Rain guards are installed over the air return and vent fan to keep water from entering the cabinet.




Figure 44 – Vent Fan and Air Return Locations

### 2.19.1 Rain Guard Hood Installation

If you find it necessary to access the fan enclosure you will need to uninstall and reinstall the rain guard that covers the fan enclosure. Follow the steps below for installation (removal is reverse of installation):

- Center rain hood cover onto cabinet frame by lining up cover holes with the 7 holes on the cabinet.




Figure 45 – Fan Hood Mounting

- Insert and tighten fasteners down. As fasteners are tightened the cover will be pulled down onto the cabinet creating a seal.

### 3. Start-Up and Maintenance Procedures

Read this section thoroughly before attempting to commission the Desert Aire dehumidifier. A complete start-up will minimize operational problems and expensive callbacks. The start-up will be quicker and easier if there is a heat and humidity load present in the space. Energize any auxiliary air and pool water heaters before the start-up so that the air and water are at their design temperatures. **Crankcase heater should be energized for 24 hours before refrigeration system is allowed to operate.**

#### 3.1 Preliminary Inspection

Verify that all contractors have completed their work. Find the Desert Aire “SP Start-Up Report”, which is located near the back of this manual. You must fill out the start-up report to validate the dehumidifier warranty.

Check the following items:

- Before starting unit, remove wooden shipping blocks found beneath compressor(s).
- Before starting unit, remove restraining brackets on supply blower equipped with the spring isolation base, if applicable.
- Verify that the incoming power supply matches the rating plate of the dehumidifier. The fused disconnect and the power supply wiring must be rated to handle the minimum ampacity rating printed on the rating plate.
- With the power supply disconnected and locked, tighten all field and factory wiring.
- Check for proper phasing of the compressors per *Section 2.7*.
- Check for proper phasing of the optional remote condenser power supply. The head fan has an EC motor and will not need to be phased; however, additional fans (2nd, 3rd, 4th, etc.) should be phased. Test the phasing by “bumping” the blower contactor. Verify that the blower rotates in the proper direction. If it rotates the wrong direction, switch any two of the three wires at the power block. The fans will blow air vertically upward when they are phased correctly.
- Inspect the air filters in the dehumidifier. Replace them if necessary.
- Check the pool water piping on units equipped with the water heating option. Inspect for leaks and proper installation of components. Verify that the auxiliary pump operates, if one is used. Purge all air out of the pool water piping.
- Check the heating control valve and piping on dehumidifiers equipped with an optional hot water or steam heating coil.
- Verify that all sensors are installed and operating properly. Verify that all external wiring to dampers, exhaust blowers, auxiliary heaters, etc. is properly connected.
- Slowly open all refrigerant service valves, and tighten the valve stem packing nuts.
- Check the field and factory piping for leaks. The internal piping may have been damaged during shipping.

#### 3.2 Airflow Balancing

To ensure code compliance and long equipment service life, proper airflow must be verified by a qualified air balancer. Before you balance the airflow, locate the motor control switches located in the electrical compartment of the dehumidifier.




Figure 46 – Motor Control Switches (Disconnect Terminal Blocks with knife disconnect).  
Thin gray terminal blocks with an orange top that can be flipped open

Open the compressor switches to prevent the refrigeration system from running while you balance the air. Use the low voltage wiring diagram(s) to identify compressor knife switches. Confirm that the compressor is off to prevent the refrigeration from running while you balance the air.

### 3.2.1 Airflow Setup of SelectAir Plus™

The SelectAir Plus™ system includes features to help automate the setup and operation of the unit. The system is substantially automated and airflow balanced at the factory for the specified airflows and static pressures. At the time of start-up the supply airflow will be automatically adjusted for the actual field static pressures encountered.

In pool applications, it is critical to maintain negative space pressurization relative to adjacent spaces and the outside ambient. This prevents moisture laden air from being driven into the wall cavities and condensing. The SelectAir Plus™ unit includes provisions to measure the differential in static pressure between the space and the outdoors and help to maintain this negative static pressure in the space.

## CAUTION

The Desert Aire SP unit contains operational controls that assist in maintaining the poolroom envelope at a negative static pressure. Proper setup allows these controls to operate as intended; however, these are not safety controls. It is the responsibility of the owner / operator to ensure that proper space pressurization of the envelope. It is recommended that the pressurization be checked on a regular basis to ensure proper operation of all building systems and any issues be corrected immediately.




Figure 47 – Dehumidifier Side View Showing Direction of Airflow

### Supply Airflow Setup

1. Check the condition of the air filters. They should be relatively clean during the setup procedure. The airflows have been set at the factory based on the information provided at the time of order. Check the programmed values against the latest schedule documents.
2. With the unit supply fan and exhaust fan disabled, check the supply airflow reading and space static pressure readings on the controller display. The room zone static pressure reading should be indicated as 0.00 +/- 0.02. If out of tolerance, a small offset can be placed in the control under SERVICE MENU SENSOR OFFSETS SCREEN. Also note that the wind direction and nearby objects can have an impact on the outdoor pressure reading. Review the installation guides for proper positioning. Review the tubing running to each location for kinks or obstructions. Review adjacent spaces for impact on poolroom pressure. The exhaust airflow should read 0 CFM +/- 100 CFM. If flow rate shows greater than this, check the exhaust fan pressure transducer and provide an offset as required.

### Exhaust and Outdoor Airflow Setup

The SelectAire Plus™ system has sensors and controls that are self-balancing for exhaust and outdoor air flow rates. The unit set points are set at the factory based on the information entered at the time of order and each unit is tested to confirm that the flow rate is properly controlled.

A special outdoor airflow monitoring system in the SelectAire Plus™ system measures and controls the outdoor air flow rates in each mode of operation. Flow rates are factory set and confirmed by measurement. The unique zone pressurization control feature helps to ensure the space is negatively pressurized properly by sensing and controlling the exhaust airflow. Desert Aire SelectAire Plus™ units can be equipped with several exhaust airflow modes.

The system should be checked to ensure that the static pressure encountered in the installation are not exceedingly high as this would limit the effectiveness of the fan or damper systems. This is done by following the procedures for airflow setup below.

## Outdoor Airflow Setup

A standard SelectAire Plus™ unit has the ability to monitor and control the outside airflow rate in all occupied modes. Each unit is preset with the flow rate specified at the time of order for each mode of operation. When setting up the unit, the capability for each mode should be confirmed.

- **Unoccupied Mode Outdoor Air Setup (Units with Low Exhaust Option Only)**

In certain installations that are equipped with a Low Exhaust duct or similar device that exhausts air constantly, there may be a desire to introduce some outdoor air during unoccupied mode. The SelectAire Plus™ system allows Unoccupied Outdoor Air damper position. This allows some outdoor air into the space to relieve during unoccupied mode to prevent the slamming of doors or infiltration from unfiltered areas. Setup in this mode is done based on pressure in the zone.

1. Use controller display under SERVICE MENU ← AIRFLOW SETTINGS ← AIRFLOW SETUP and use the down arrow until the OA SETUP – UNOCC screen is shown. Set the Override to “On”.
2. Ensure that any Low Exhaust fan or device is operating in Unoccupied Mode.
3. Read the zone pressure on the display. The recommended pressure is -0.05” W.C. Should the pressure be lower than this, the Unocc OA Setpoint setting can be increased.

- **Outdoor Air Setup for All Other Modes**

Each outdoor air mode should be confirmed

1. Use controller display under SERVICE MENU ← AIRFLOW SETTINGS ← AIRFLOW SETUP and use the down arrow until OA SETUP – OCCUPIED is shown. Set the Override to “On”.
2. Let the unit control loop stabilize. You will see the damper position modulate. The control loop may take up to 5 minutes to fully stabilize. At that time Current OA CFM should match the mode OA CFM Stpt displayed. Note that some fluctuation is to be expected, particularly if heavy winds or wind gusts are directed towards the OA intake at that time, but on average the value will be close to the setpoint.
3. Note the OA damper position. Ensure this damper is not commanded to the minimum or maximum position. If it is, review to ensure that damper is physically moving and review the static pressure in the OA duct if this is an indoor unit.
4. If desired, measure the outdoor air flow rates independently through the use of direct measurement device such as hood, velgrid, or anemometer.
5. Repeat the procedure for the other outdoor air modes as desired by scrolling through the screens and changing the override for each mode. The modes available are dependent on the types requested at the time of unit order. These may include “Event”, “Max. OA”, and “Purge”. Note that controller power will need to be removed after completing “Purge” mode as the post-purge operation will lock out outdoor air operation for 30 minutes after purge.

The flow rate for each mode can be adjusted in the field through the controller, but it should be noted that there may be physical limitations to the amount of flow that can be introduced. Also, note that very low return air static pressures may limit the amount of outdoor air that can be introduced. The very low return air static pressures are encountered and there is a desire for high outdoor air flow rates, a restriction or damper may need to be placed in the return air duct. Consult the factory for further recommendations.

## Exhaust Airflow Setup

The unit exhaust airflow rate should be confirmed for each mode that was specified at the time of order to ensure that the duct system static pressure encountered allow for proper flow and zone negative pressurization. Ensure all doors and windows to adjacent spaces or outdoors are closed before balancing the exhaust air.

1. Review the exhaust air flow rates for each mode programmed into the controller display under SERVICE MENU ← AIRFLOW SETTINGS ← AIRFLOW SETUP ← MAX EXH. FLOW RATE. These settings have been factory pre-set to the airflow indicated at the time of unit order. It should be noted that these flow rates act as maximum flow rates for each mode of operation. The controls attempt to achieve a negative zone pressure.
2. Use the controller display under SERVICE MENU ← AIRFLOW SETTINGS ← AIRFLOW SETUP ← EXHAUST AIRFLOW SETUP to set the Set Unit Override to the first mode to be tested. Set Exhaust Mode to “Cool”. Ensure the “Ex Max” is set to 100%. Unit will open the Cool Air Exhaust Damper downstream of the evaporator coil. Units specified with high amounts of exhaust air may also open the exhaust damper upstream of the coil in this mode.
3. Allow unit to stabilize. Fan speed, damper positions (see *Section 3.2.2*), and zone pressure should be relatively constant.
4. Review the fan speed. A speed of 90% or greater in any mode may indicate high exhaust duct static pressures or static pressure set point that is too high. Correct any issues with exhaust duct routing, size, or total length.
5. Review the zone static pressure. The recommended zone pressure is -0.050” W.C. for poolrooms. A building envelope that allows significant infiltration may not be able to achieve set point. **Positive pressures in a pool space will potentially cause condensation in the wall cavity, mold growth, and property damage.** Should the zone not reach pressure setpoint, it is highly recommended that the maximum CFM in the MAX EXH. FLOW RATE screen be increased for that mode of operation.
6. Review the actual zone static pressure through the use of independent measurement device such as a manometer or magnehelic. This can usually be done by slipping the manometer tubing through a door or window leading outside.
7. If desired, measure the exhaust air flow rates through the use of direct measurement devices such as hood, velgrid, or anemometer.
8. Repeat the procedure for the other modes as desired by changing the Exhaust Mode. The modes available are dependent on the types requested at the time of unit order. These may include “Unocc”, “Occ”, “Event”, and “Max. OA”, and “Purge”. Note that controller power will need to be removed after completing “Purge” mode as the post-

purge operation will lock out outdoor air operation for 30 minutes after purge.

It should be noted that filter changes are important to ensuring that exhaust air and outdoor air are able to be maintained at the proper flow rates. The SelectAire Plus™ system operation will automatically adjust to accommodate normal increase in static pressure drop, but excessive filter loading will restrict airflow. Filters should be monitored and replaced as required.

### Evaporator Settings and Cool Exhaust Airflow

There may be additional display screens for the evaporator and cool exhaust airflow. The values are present from the factory and optimized. No adjustment is required unless instructed by the Desert Aire Service.

### 3.2.2 Final Air Balancing

Once the supply air and exhaust air setup have occurred, the unit will automatically adjust the damper positions and drive speed in each mode of operation.

The outdoor air damper will open and modulate to achieve the pre-determined pressure drop set point of the outdoor air stream pressure plate. This has been determined by the customer requested occupied mode flow rate and tested at the factory. The exhaust will be controlled by space pressurization and maintains the negative static pressure set point.

At this point there is a good opportunity to ensure that the commands for operational modes are being properly sent to the equipment. Command each mode of operation through the method that will be used on site. Depending on the mode and installation specific, this may occur through the internal time schedule, a contact closure, or the Building Management System. When the actuator is commanded to 0% the damper should close and when the actuator is commanded to 100% the damper should be fully open. A special Manual Damper Setup screen has been added to the commissioning menu in the controller program (See Figure 44). “M” represents manual setup and “A” represents automatic manual position. This allows the user to manually command each damper to both open and closed positions.




Figure 48 – Damper Setup Screens



1. Ensure correct damper orientation. Note that some dampers have an upstream and downstream side and/or a top and bottom orientation.
2. Confirm that the actuator is firmly attached to the pre-mounted actuator bracket.



3. Fully open the damper using the controller manual override (100% command). Ensure there is no binding or resistance during rotation.
4. Rotate the damper to the closed position (0% command), noting the direction of rotation when doing so.
5. Ensure the actuator is in the closed position. If this is a spring return actuator it should be in the closed position. If this is not spring return, depress the manual release and rotate the actuator hub in the same direction that you rotated the damper in the previous step.
6. While holding the damper in the closed position, tighten the actuator to the damper jack shaft. Tighten the two nuts on the clamp using a wrench or socket using 6-8 ft-lb of torque.
7. Set the switch on the actuator for the direction of the rotation per the directions below.
8. Inspect the damper for any potential leakage in the closed position. Seals should have pressure on them. Pay particular attention to dampers with more than one segment served by a “jumper bracket” or other linkage. Adjustment to that linkage may be required for full sealing.
9. Depress the manual release on the actuator and rotate the damper to the full open position. You may need to use the supplied crank handle when moving spring-return actuators. Inspect again for binding or unusual resistance.
10. Return the controller command position to automatic and monitor the actuator rotation to confirm correct installation.

The Rotation of the both Non-spring and spring return actuators are detailed below.

### **Non-Spring Return Actuators Rotation**

Non-spring return actuators have a reversing switch on the cover. Switch position indicates the start point. During checkout, the switch position can be temporarily reversed and the actuator will reverse its direction. This allows the technician a fast and easy way to check the actuator operation. With the switch in position 1, the actuator rotates clockwise () with a decrease in voltage or current. With the switch in position 0, the actuator rotates counterclockwise () with an decrease in voltage or current. See Figure 49.






Figure 49 – Non-Spring Return Damper Positions

### Spring Return Actuators Rotation

Actuator rotation direction confirmation instructions.

Manually move the damper to the fail-safe position. If the shaft rotated Counterclockwise (↺), this is a CCW installation. If the shaft rotated clockwise (↻), this is a CW installation. In a CCW installation, the actuator side marked “CCW” faces out, while in a CW installation, the side marked “CW” faces out. See Figure 50.




Figure 50 – Spring Return Damper Positions

## CAUTION

The Desert Aire SP unit contains operational controls that assist in maintaining the poolroom envelope at a negative static pressure. Proper setup allows these controls to operate as intended; however, these are not safety controls. It is the responsibility of the owner / operator to ensure that proper space pressurization of the envelope. It is recommended that the pressurization be checked on a regular basis to ensure proper operation of all building systems and any issues be corrected immediately.

## **Final Review of the Unit Operation**

Under typical circumstances, the unit will cycle into and out of a mode of operation over a period of time. This will typically continue until the environmental conditions change or another outside influence causes the load to differ. The duration of each cycle will depend on the unit capacity and the activity within the space as well as the building construction, set point, and ambient conditions.

The controller is programmed with minimum mode times that prevent short compressor cycles and quick indexing of modes. This minimum mode time is set at 360 seconds as a default. When the loads are very low and the unit is relatively large for the application, this may cause a slight overshoot in space condition for cooling and dehumidification. Frequent cycling between heating and cooling is not expected, however. It is recommended that as a final check that the unit be released from all overrides, offsets, and returned to the expected set points. Observation of the typical operation under load is an invaluable tool in ensuring that all aspects of the system are working as anticipated. Observing the unit control the space for a few cycles is recommended. This can be done reasonably well as the tools and site is being cleaned up at the end of the startup or service call.

### **3.3 Refrigeration Testing**

Refrigeration based cooling systems are sometimes referred to as “sealed systems”. This is in reference to the refrigeration system being hermetically sealed, no refrigerant can leave the system and no contaminants are allowed inside. Factory equipment and procedures ensure a clean and tight refrigeration system where only the specified refrigerant and oil are in the system. This is a critical component to the longevity of the system.

Some Desert Aire systems are shipped in sections to allow for installation of some of the sections in a location much different from another. An example is a unit with a remote condenser ready circuit. The dehumidifier may be installed indoors near the conditioned space while the remote condenser used to reject waste heat is located outdoors. The piping of the condenser is completed in the field before the unit is commissioned. The design and processing of the field piping is just as important as the factory piping in ensuring the longevity of the system.

Selection of quality components, quality procedures, and full testing help to ensure the sealed system failures are minimized wherever possible. Nonetheless, the mechanical nature of many components creates some unforeseen wear and failure in certain instances. Some units may need service at a point in the life of the product that requires opening of the hermetic refrigeration system. Special care must be taken to ensure that the system is returned to service without any contamination.

Whenever servicing Desert Aire equipment, observe the following:

- Use only equipment rated for the pressures and the refrigerant being serviced.
- Use only equipment dedicated to service of the refrigerant in the system. Do not use equipment to service multiple refrigerant types.
- Purge all hoses and equipment of non-condensable gasses before connecting to the sealed system.
- Use only original equipment parts or factory approved equivalent for servicing.
- Use only refrigerant system oil.

- Minimize the time the system is open to atmosphere while servicing. Cap all connections when there is no active service work on the system. This is particularly important with units that contain POE oils as moisture will be absorbed quickly and cannot be removed with a vacuum.
- Never open the system while under a vacuum. Should the system require opening to repair a leak or other service when in a vacuum, fill with dry nitrogen to atmospheric pressure before opening.
- Have a Schrader core replacement tool available when servicing the refrigeration system. Although rare, defective or damaged Schrader valve cores can contribute to refrigerant loss.
- Charge systems only by weight after servicing. Review the rating plate and any field charge labels.
- When servicing, additional liquid line filter dryers and suction filters may be required. This does not apply to installation of remote condensers.
- Charge refrigerant blends, including R-410A and R-407C, with liquid only. Charging should be done into the high side of the system whenever possible. Refer to *Section 5.6* for additional procedures related to charging.

Note that the superheat should be stable and within 7 degrees. The temperature and relative humidity listed in Figure 51 is the Return Air. Minimum value for superheat at compressor in all modes:

Superheat Minimum Values Chart Temp (°F)							
Relative Air Temperature (°F)		60.0-65.0	65.1-70.0	70.1-75.0	75.1-80.0	80.1-85.0	85.1-90.0
Relative Air Humidity (%RH)	30.0-40.0	12	13	14	15	15	16
	40.1-50.0	13	14	15	15	16	18
	50.1-60.0	13	14	15	16	18	18
	60.1-70.0	14	15	15	16	18	19
	70.1-80.0	14	15	16	18	19	20

Figure 51 – Superheat Minimum Values Chart

### 3.4 General Testing

After you balance the airflow and test the refrigeration circuits, verify that the other equipment and accessories connected to the dehumidifier work properly. Although this may be difficult, since the dehumidifier is usually interlocked with a variety of equipment installed by different contractors, you must not skip this step.

Each of these devices (which may include auxiliary air and water heaters, smoke alarms, circulating pumps and a building management system) is vital in maintaining the performance and comfort of the swimming pool environment. Many customer complaints are caused by improper interlocks between these devices. Make sure you check the following:

- Check the outdoor air and exhaust devices. The outdoor air and exhaust dampers must open when they receive an “occupied” signal from the dehumidifier. If you have installed an exhaust blower, make sure that it is interlocked with the “occupied” signal or with an end switch on the outdoor air damper actuator.

- Check the condensate drain to make sure it has been trapped and primed with water. Verify that it drains freely, with no leaks. If the drain is outside or in an unconditioned space, make sure it has been heat traced. If you installed a condensate pump, make sure it operates properly.
- Check the pool water piping to the dehumidifier (on units equipped with optional pool water heating). Make sure that all air has been bled out of the lines, and check that an air bleed valve has been installed at any high points in the water lines. If the circulating pump is not set for continuous operation, make sure it properly interlocked with the dehumidifier. Temporarily shut off the water flow to the unit to verify that the factory-installed water flow proving switch operates correctly. Verify that the pool water temperature sensor has been installed where water will flow over it continuously. Verify that the pool water temperature sensor is on the water inlet of the unit.
- Check the operation of the remote condenser (on units equipped with this option). Make sure that the pressure transducers are wired to the condenser fan cycling control, the cut-in and cut-out pressures are correctly set per the remote condenser installation manual. Verify that the fans are blowing vertically upward when they run.
- Check the temperature and humidity readings displayed on the controller. If you think the values are incorrect, check the sensor or its field-installed wiring for damage. If necessary, check the voltage jumper on the temperature and humidity sensor. It must be set in the "0-10 VDC" position.

## **3.5 Routine Maintenance Schedule**

### **3.5.1 Service Every Month**

- Check and replace the air filters in the return duct and the outdoor air duct.
- Check for dirty coils in the dehumidifier. Clean them if necessary.

### **3.5.2 Service Every Four Months**

#### **3.5.2.1 Reheat Condenser Coil Cleaning**

Refrigerant coils or other components that corrode due to improper cleaning, improperly balanced pool chemistry or corrosive air quality will not be covered under the warranty.

#### **Maintenance**


- When cleaning the condenser open the normally closed condensate valve shown in Figure 52. Close this valve when the cleaning process is complete.
- Filters should be inspected on a regular basis and changed as needed. Maintaining clean filters is a cost-effective way to help maintain maximum coil performance and service life.
- Periodic inspection of the coil for signs of corrosion and for leaks is recommended. Small leaks can be detected using a Halide torch. Repair and replacement of the coil and the connecting piping, valves, etc., should be performed as needed by a qualified individual.
- Routine cleaning of the coil surface is needed to maintain optimum performance. Caution should be exercised in selecting the cleaning solution as well as the cleaning equipment.
- Use of high-pressure water can cause damage to the fin surface. Low pressure water is recommended when cleaning the coil. Improper selection can result in damage to the coil and/or health hazards.

- Clean the coil from the leaving airside so that foreign material will be washed out of the coil rather than pushed further in. Be sure to carefully read and follow the manufacturer's recommendations before using any cleaning fluid.
- The use of filter-driers in the system piping is recommended along with a sight glass that has a moisture indicator. Replace the filter dryer(s) as needed. See *Section 2.17*

**Note:** Refrigerant conversions are beyond the scope of this manual and should only be performed by qualified parties.

Surface loaded fibers or dirt should be removed prior to cleaning and/or water rinse to prevent further restriction of airflow. If unable to back wash the side of the coil opposite that of the coils entering air side, then surface loaded fibers or dirt should be removed with a vacuum cleaner. If a vacuum cleaner is not available, a soft non-metallic bristle brush may be used while brushing with the fins, typically vertically for RTPF coils. Coil surfaces can be easily damaged (fin edges bent over) if the brush is applied across the fins.


**Note:** Use of a water stream, such as a garden hose, against a surface loaded coil will drive fibers, dirt and salts into the coil. This will make cleaning efforts more difficult. Surface loaded fibers must be completely removed prior to completing low velocity cleaning and water rinses.



*Figure 52 – Condensate valve location*

If an optional condensate float switch is included, maintenance should consist of inspection to see that the float is free to move and not coated with any substance. Build up on the float would change its weight or volume significantly. If this occurs, the float should be cleaned. This is easily accomplished without disturbing the installation. In addition, the steam may be whipped down to remove any build-up. See Figure 53 for an image of a clean condensate float.





*Figure 53 – Clean Condensate Float Switch*

#### **3.5.2.2 ElectroFin Coated Coil Cleaning**

Dehumidifiers equipped with the ElectroFin coated coils must be cleaned regularly.

A scheduled and documented QUARTERLY cleaning procedure is REQUIRED for all HVAC/R equipment coated with ElectroFin coil and/or cabinet protection.

#### **Required quarterly cleaning and chloride removal of ElectroFin coated equipment**

Quarterly cleaning is required to maintain warranty coverage and is essential to maintain the life of an ElectroFin coated coil and cabinet. Coil and cabinet cleaning shall be part of the unit's regularly scheduled maintenance procedures. Failure to clean an ElectroFin coated coil or cabinet on the prescribed quarterly cycle will void the warranty and may result in reduced efficiency and durability in the environment.

A routine two-step quarterly coil cleaning is required to maintain warranty. Step one is to clean the coil with the below approved coil cleaner (see approved products list under the "Recommended Coil Cleaners" section). Step two is to use the approved salt/chloride remover under the "Recommended Chloride Remover" section to dissolve soluble salts and revitalize the unit. It is very important when cleaning and/or rinsing not to exceed 130°F and potable water pressure is less than 100 psig to avoid damaging the unit and coil fin edges.

#### **Recommended Coil Cleaners**

The following are recommended coil cleaners, assuming it is used in accordance with the manufacturer's directions on the container for proper mixing and cleaning. They have been approved for use on ElectroFin coated coils to remove mold, mildew, dust, soot, greasy residue, lint and other particulate. Never use any cleaners that are not approved.

**Coil Cleaner**

GulfCoat™ Coil Cleaner

**Reseller**

Desert Aire Parts Dept.

Tel: (262) 946-7400

Email: service@desert-aire.com

**Recommended Chloride Remover**

The following chloride remover is recommended, assuming it is used in accordance with the manufacturer's directions on the container for proper mixing, has been approved for use on ElectroFin coated coils and cabinets to remove chloride/salts and sulfates. Never use any chloride removers that are not approved.

**Chloride Remover**

CHLOR\*RIDE®

Concentrate

**Reseller**

Desert Aire Parts Dept.

Tel: (262) 946-7400

Email: service@desert-aire.com

**Harsh Chemical and Acid Cleaners**

Harsh chemicals, household bleach or acid cleaners should not be used to clean outdoor or indoor ElectroFin coated coils. These cleaners can be very difficult to rinse out of the coil and can accelerate the corrosion attack of the coil.

**High Velocity Water or Compressed Air**

High velocity water from a pressure washer or compressed air should only be used at a very low pressure, (< 100 psi), to prevent fin and/or coil damages. The force of the water or air jet may bend the fin edges and increase airside pressure drop. Reduced unit performance or nuisance unit shutdowns may occur.

**Detailed Protection Plan Instructions:**

The Warranty Protection plan consists of a two-step process. Step 1 is to clean the coils and step 2 is to remove the salts/chlorides. The coils are to be thoroughly cleaned using an approved coil cleaner as listed previously. Once cleaned, they will then need to have the chlorides/salts removed by using preferred chloride remover as listed previously.

**Warranty Protection Step 1 of 2**

- Complete the coil cleaning following these steps
- Ensure that the power to the unit is off and locked out.
- Clean the area around the unit if needed to ensure leaves, grass or loose debris will not be blown into the coil.
- Remove panels or tops as required gaining access to the coil(s) to be cleaned.
- Using a pump up sprayer, fill to the appropriate level with potable water and add



the correct amount of approved cleaner as per manufacturer instructions leaving room for the pump plunger to be reinserted.

**NOTE:** Coils should always be cleaned / back flushed, opposite of airflow to prevent impacting the direct into the coil

- If the coils have heavy dirt, fibers, grass, leaves, etc. on the interior or exterior face areas, a vacuum and brush should be used to remove those surface contaminants prior to applying cleaner. The interior floor, drain tray or pan areas should also be vacuumed.

Apply the mixed cleaner to coil surfaces using a pressurized pump up sprayer maintaining a good rate of pressure and at a medium size nozzle spray, (not a solid stream and not a wide fan but somewhere in the middle). Work in sections/panels ensuring that all areas are covered and kept wetted.

- Apply the mixed cleaner to coil surfaces using a pressurized pump up sprayer maintaining a good rate of pressure and at a medium size nozzle spray, (not a solid stream and not a wide fan but somewhere in the middle). Work in sections/panels ensuring that all areas are covered and kept wetted.
- Apply the cleaner to unit interior air exiting side of coil surfaces first. Work in sections/panels moving side to side and from top to bottom.
- Generously soak coils by spraying cleaner directly on and into the fin pack section to be cleaned and allow the cleaner solution to soak for 5 to 10 minutes.
- Using pressurized potable water, (<100 psi), rinse the coils and continue to always work in sections/panels. Start at the top of the coil and slowly move vertically downward to the bottom. Then, staying in the same vertical area, slowly move back up the top where you started. Now move over slightly overlapping the area just completed and repeat above. Continue until all coil areas on the inside of the unit have been rinsed.

Complete steps below for the exterior air entering side of the coils

- Final rinse – Now complete a quick rinse of both sides of the coil including the headers, piping, U-bends and hairpins.
- If the coil has a drain pan or unit flood that is holding rinse water or cleaner, extra time and attention will need to be taken in those areas to ensure a proper rinse has been completed.

## Warranty Protection Step 2 of 2

Complete the coil chloride (salt) removal following these steps

- CHLOR\*RID® is a concentrate to be used for both normal inland applications at a 100:1 mix ratio OR for severe coastal applications 50:1 mix ratio with potable water, (2.56 ounces of CHLOR\*RID® to 1 gallon of water). Using a pump up sprayer, fill to the appropriate level with potable water and add the correct amount of CHLOR\*RID® salt remover leaving room for the pump plunger to be reinserted.
- Apply CHLOR\*RID® to all external coil surfaces using a pressurized pump up sprayer maintaining a good rate of pressure and at a medium size nozzle spray, (not a solid stream and not a wide fan but somewhere in the middle). Work in sections/panels ensuring that all areas are covered and kept wetted.
- Generously soak coils by spraying CHLOR\*RID® directly on and into the fin pack section. Let stand 5 to 10 minutes keeping the area wetted. Do not allow to dry before rinsing.
- Using pressurized potable water, (< 100 psi), rinse the CHLOR\*RID® and dissolved chlorides/salts off of the coils continuing to always work in sections/panels.
- Starting at the top of the coil, begin rinsing the coil from side to side until you reach the bottom. Repeat as many times as is necessary to ensure all coil sections/panels have been completed and are thoroughly rinsed.
- Reinstall all panels and tops that were removed.

### 3.5.3 Service Every Six Months

- Check and tighten all field and factory electrical connections.
- Check for dirty coils in the dehumidifier and the optional remote condenser.
- Check and clean the drain pans and blow out the condensate drain line.
- If the drain is plugged, water will back up into the dehumidifier and flood the mechanical room.
- Check and adjust the air flow per specifications.
- Dirty ducts, filters, and coils may have reduced the total air volume.
- Check the operating pressures of the refrigeration circuits.
- Check the current draw of each blower motor.
- Check the current draw of each compressor.
- Note that the bearings on fan motors are permanently lubricated and do not require regular lubrication.

**NOTE:** Please have the following information available if you need to call the Desert Aire Service Department:

- Model Number
- Serial Number
- Room Temperature
- Relative Humidity
- Operating Refrigeration Pressures
- Water Temperature
- Compressor Amperages
- Blower Motor Amperage(s)

### 3.5.4 Blower / Fan Maintenance

Maintenance operation is only to be performed by trained service personnel. Observe all state and local safety regulations including wearing safety shoes, eye protection and gloves. It is imperative that the motor must not be rotating and that the electrical circuit is open and secured against being switched back on. To check that the fan is not running, verify the absence of voltage. Keep the airways to the fan free to prevent objects from falling or coming through the fan opening. The area must be dry.

## DANGER

**Wet cleaning under voltage may lead to an electrical shock and/or death.**

- Regular inspection and, if necessary, cleaning is necessary to prevent a blade imbalance due to the ingress of dirt.
- Clean the fans flow area and entire fan with a moist cloth.
- Do not use aggressive, paint solvent cleaning agents when cleaning.
- Never use a high-pressure cleaner or spray jet to clean.
- Avoid letting water permeate into the motor and the electrical installation.
- After cleaning, the motor must be operated for 30 minutes at 80-100% of the maximum rpm to dry out. This will allow any possibly penetrated water to evaporate.
- Motors are maintenance-free as they have bearings with “lifetime lubrication”. If it is necessary to replace the bearings due to damage or if they are at the end of the grease consumption period. Signs of damage include abnormal operating noise or excessive vibration. If necessary, replace bearings only with original parts.
- Outdoor fans: If a fan is stationary for long periods in a humid atmosphere, it should be switched ON for minimum of two hours every month to remove any moisture that may have condensed within the motor.

### 3.5.5 Auxiliary Heater – Hot Water Coil Maintenance

#### General

- Periodic inspection of the coil for signs of corrosion and/or leaks is recommended. Repair and replacement of the coil and the connection of piping, valves, etc., should be performed as needed by a qualified technician.
- Should the coil surface need cleaning, caution must be exercised in selecting the cleaning solution as well as the cleaning equipment. Improper selection can result in damage to the coil and/or health hazards. Clean the coil from the leaving air-side so that foreign material will be washed out of the coil rather than pushed further in. Be sure to carefully read and follow the manufacturer's recommendations before using a cleaning fluid.
- The circulated fluid must be free of sediment, corrosive products and biological contaminants. Periodic testing of the fluid followed by any necessary corrective measures along with maintaining proper fluid velocities and filtering of the fluid will help to satisfy this goal.
- If automatic air vents are not utilized, periodic venting of the coil is recommended to remove accumulated air. Caution should be exercised to avoid injury. High pressure and/or high temperature fluids can cause serious injury.

#### Blowing-Out Coils

- Isolate the coil from the rest of the system by closing the valves on both the supply and return.
- Drain the coil by opening all drain valves and/or the drain plug. Remove the vent plug to aid the draining process.
- Once the coil has been fully drained, the blower can be hooked up. Caps installed in the piping on straight runs going to the supply and return connections are ideal points to hook up the blower. The air vent and drain plug are not suitable locations for hooking-up the blower. Caution should be exercised when installing the blower. The blower operator must take precautions to insure that water does not come into contact with any of the electrical components of the blower. Failure to do so may result in damage to the equipment and serious injury.
- Close the vent or drain plug on the header which the blower is connected and open the drain valve or cap on the other header.
- Operate the blower for 45 minutes and then check the coil to see if it is dry. A mirror placed in the discharge will become fogged if moisture is present. Repeat this procedure until the coil is dry.
- Let the coil stand for several minutes then blow it out again. If water comes out, repeat the blowing operation.
- Leave all plugs out of the drains open until the threat of freezing has passed.

#### Flushing Coils

- We recommend the use of inhibited glycol designed for HVAC applications for corrosion protection. The use of uninhibited glycol has produced formicary corrosion in copper tubing. The complete filling of water coils with an inhibited glycol solution for freeze protection can be expensive. In some instances, it is more cost effective to flush the coils

with an appropriate concentration of inhibited glycol solution. Residual fluid can be left in the coil without the threat of freeze damage provided the correct concentration of inhibited glycol was used. The recovered fluid can then be used to flush other coils. Select an inhibited glycol solution that will protect the coil from the lowest possible temperatures that can occur at the particular coil's locality. The following tables have been provided for convenience.

Estimate the volume of the coil in gallons:

For 0.625" tubes (1.5" face tube spacing):

$$\text{fin height (in)} \times \text{finned length (in)} \times \text{\# of rows} \times 0.0011 = \text{gallons}$$

For 0.5" tubes (1.25" face tube spacing):

$$\text{fin height (in)} \times \text{finned length (in)} \times \text{\# of rows} \times 0.00083 = \text{gallons}$$

- Isolate the coil from the rest of the system by closing the valves on both the supply and return lines.
- Drain the coil by opening all drain valves and/or the drain plug. Remove the vent lug to aid the draining process.
- Close the drain valve(s) and drain plug.
- Connect the flushing system to the coil. A typical system is shown in Figure 54
- With the throttling valve closed, start the pump and operate until the air vented from the coil. Next, close the air vent.
- Open the throttling valve about half-way and circulate the fluid through the coil for 15 minutes. Check the strength of the fluid. A hydrometer or test kit from the fluid manufacturer is suitable for this application.
- Adjust the solution strength as needed and circulate the fluid for another 15 minutes.
- Repeat steps above until the desired concentration is reached.
- Shut the pump down and drain the inhibited glycol from the coil.
- The recaptured fluid can be used to flush other coils.

**NOTE:** Be sure to follow the manufacturer's recommendations before utilizing any glycol based anti freeze solution. Additional fluid will be required for the pump, connected piping and fluid reservoir. Formulas are for estimation purposes only.




Figure 54 – Flushing System

## 3.6 General Service

### 3.6.1 Filter Drier Replacement

#### 3.6.1.1 When to Change Cores

Cores should be changed when they become contaminated. Disposal of the cores should be handled according to local law.

- Solids – Cores that become contaminated with solid particles should be changed whenever the pressure drop increases to the point where it reduces system performance.
- Moisture – When moisture is the major concern, change the drier when the Moisture and Liquid Indicator color is in the caution or wet range. The action of the indicator element is completely reversible and will change color whenever the moisture content of the system changes, see *Section 2.17*.
- Other – When either acid or wax is the major contaminant involved, the cores should be left in the system at least three days to come to equilibrium thereby removing the maximum amount of contaminants.

The cores will remove their maximum amount of moisture and come to equilibrium in approximately one day of operation. Many users of replaceable core will change the cores every spring and fall as part of their normal maintenance schedule.

#### 3.6.1.2 Instructions for Assembly and Charging Cores

Filter drier cores are shipped in metal cans that are dried and hermetically sealed to protect

the cores from contamination by moisture and dirt. The detailed instructions for assembly and changing cores are given in these cans.

The following condensed instructions may be used if these cans are not available:

1. Make sure all the refrigerant is pumped out of the Catch-All shell. The appropriate shut-off valves should be tightly closed.
2. Remove the end plate and internal assembly, and clean the internal parts. Remove the activated core from the sealed can using caution when doing so. The metal pull tab and pull strip permit the can to be rolled opened with the key or a pair of pliers. Do not replace the end plate gasket unless it is damaged. When replacement is necessary, select the outer gasket from the set supplied with each core. Do not cut or abrade the gaskets used in the end plate.
3. Remove the end spring, wing screw, and inlet plate from outlet plate assembly. Remove core spacer plates from assembly (if applicable). If desired, install secondary filter. (Detailed installation instructions are packaged with the secondary filter.)
4. Assemble the molded cores and use the core spacer plates as required. After the cores are assembled, position inlet plate on the end of the tubular screen. Fasten finger tight the wing screw to assembly. The screw, when properly fastened, tightens the components in the assembly thereby prohibiting component movement and dirt bypassing around the cores. Assemble the end spring on to the wing screw. The design of the screw holds the spring in position so that the end plate can be easily installed (especially when the shell is mounted horizontally). The end spring is designed to fit into the circular groove on the end plate.
5. Insert the assembly in the shell, replace the flange bolts, tighten evenly, using a star pattern, to the recommended torque value, 25-30 ft-lbs for the C-R420 Series, and C-480 through C-19200 Series, and the C-30000 and C-40000 Series.
6. For C-R424, C-R425 and C-R427 models – do not remove the outlet strainer assembly or gasket. On these models, the core retainer assembly with the spring is the only part that must be removed to change the core.

#### **Caution**

The edge of the shell fits into the gasket groove on the end plate and makes a seal against the gasket to prevent refrigerant leakage. Be careful not to scratch or damage the edge of the shell when changing the cores. If the edge of the shell should become damaged, replace the shell to prevent possible refrigerant leakage.




Figure 55 – Filter Drier Assembly



## 4. Troubleshooting

Although Desert Aire dehumidifiers have been designed for reliable and trouble-free operation, you may occasionally encounter a service-related problem. If you cannot immediately diagnose a fix to the problem, do not be intimidated by the apparent complexity of the dehumidifier. Your common sense and experience can help you solve the majority of these problems.

These problems or complaints are frequently caused by improper interlocks between the dehumidifier and the other equipment and accessories at the jobsite. You may need to consult with other contractors who have worked on different portions of this project. Read *Section 3.4* for a more detailed list of interlocks.

The following list will help you diagnose some of the most obvious symptoms of a system which does not work properly.

### 4.1 The Blower Does Not Run

The standard Desert Aire dehumidifier is designed for continuous blower operation, which helps prevent air stratification, occupant discomfort, and structural damage to the ceiling and upper walls of the poolroom.

Check for these problems:

- Check for power at the power block on the electrical panel of the dehumidifier.
- Verify that the incoming power matches the value printed on the unit rating plate.
- Check the branch fusing. Replace any defective fuses and determine why they failed.
- Use a voltmeter to trace the low-voltage control wiring. Determine if voltage is applied to the holding coil of the blower contractor. If there is no voltage at the holding coil, check the blower overload, the control transformer, the smoke alarm interlock, or the optional voltage monitor relay.
- If the dehumidifier uses a non-standard controller, or if the blower is cycled by the building management system, consult with the controls contractor.

### 4.2 The Compressor(s) Do Not Run

If a compressor doesn't run even though the humidity in the poolroom is excessive, check the sequence of operation of the dehumidifier. Under certain situations the controller will lock out the compressors to prevent the pool room from overheating. See *Section 5.5* in the Appendix for more details. If the problem is not controller-related, check the following:

- Check the "Compressor Fault" indicator on the controller display panel (for dehumidifiers with the standard controller). The fault indicator will flash if one of the compressor safety devices has tripped. The indicator will automatically stop flashing when the problem has been corrected. See the low-voltage wiring schematic for details on this fault circuit. Check for power at the power block on the electrical panel of the dehumidifier.
- Verify that the incoming power matches the value printed on the unit rating plate.
- Use a voltmeter to trace the low-voltage control wiring. Determine if voltage is applied to the holding coil of the compressor contactor.

- If there is no voltage at the holding coil, check the compressor overload and safety devices, the control transformer, the smoke alarm interlock, the airflow proving switch, or the optional voltage monitor relay.
- If the dehumidifier uses a non-standard controller, or if the compressors are cycled by the building management system, consult with the controls contractor.
- Confirm that the compressor “knife” switches from air balancing section have been closed.

### 4.3 High Pressure Alarms / Readings Above 575 PSIG

The unit contains a pressure transducer and control sequence that will interrupt power to the compressor if the refrigeration system pressure is excessively high. The alarm will be active on the local display and the building management system (if equipped). The alarm can be reset at the main alarm screen on the display.

- Check that all service valves and ball valves in the compressor discharge line are fully open.
- Verify that the reheat condenser is clean and free from debris. Use a Magnehelic® or an inclined manometer to check the air volume through the reheat condenser.  
See *Section 3.2* for more detailed instructions.
- Check that there is adequate water flowing through the pool water condenser (on units equipped with this option). Verify the operation of the water flow switch.
- Check the remote condenser fuses, fan motors, and fan cycling switches (on units equipped with this option). Verify that the fans are not obstructed and that they blow the air vertically upward.
- Check the three-way heat reclaim valve for proper operation. This valve, which is installed in the compressor discharge line, diverts hot refrigerant vapor to the various condensers (on units equipped with optional pool water heating or remote condensers). The valve spool may be stuck in the middle of the valve, where it blocks the outlets to both condensers. You can verify its operation by first running the compressor and then measuring the temperature of both condenser outlets. If the valve is shifting normally, the active condenser outlet will heat up rapidly.
- Check for air or other non-condensable in the refrigeration circuit. Desert Aire installs purge ports in the highest point of each condenser’s discharge line. To purge these gases from the system, temporarily run the compressor while you energize the selected condenser. Slowly depress the Schrader core at the high point purge of the condenser. You can do this procedure to keep the system running, but it is a temporary fix. It is not a long term substitute for proper evacuation with a vacuum pump.
- If the dehumidifier uses an outdoor air duct with a field-installed preheating coil, verify that the coil is only active during the heating season.
- If the system is overcharged or excessively cold, migrating refrigerant can liquefy and fill a condenser and its discharge line during the “off-cycle”. If the compressor starts and the three-way valve shifts to this flooded condenser, the high pressure switch will trip almost immediately. Remote outdoor condensers are particularly susceptible to this problem during the winter months.

#### 4.4 Low Pressure Alarms / Evaporator Coil Icing

The unit contains a pressure transducer and control sequence that will interrupt power to the compressor if the refrigeration system pressure is excessively low. The alarm will be active on the local display and the building management system (if equipped). In this active alarm state, the circuit will stop and not restart until the Suction Pressure in that circuit rises 48 psi above the Low Suction Pressure Trip Set Point. Although the circuit will restart automatically, the red ALARM LED on the display will stay lit until the alarm is acknowledged, even after the alarm condition is cleared, to alert the operator the alarm occurred. The alarm can be reset at the main alarm screen on the display.

- Check the return air ductwork. Poorly designed, restrictive ductwork can cause stratification or faulty air distribution. Resize the return air ductwork and grilles, or add turning vanes if necessary.
- Verify that the evaporator and return air filters are clean and free from debris. Review the system controller reading and use a Magnehelic® or an inclined manometer to check the air pressure drop through the evaporator coils. See *Section 3.2* for more detailed instructions.
- Check the temperature and humidity of the return air. The SP evaporators are designed for maximum efficiency at typical swimming pool conditions. If the return air wet bulb temperature drops below 60°F, these coils may frost. Never introduce unconditioned outdoor air into the return duct of an SP series dehumidifier.
- Check that all service valves and solenoid valves in the liquid line are energized or fully open.
- Verify that there are no restrictions or debris in the liquid line solenoid, the filter/drier, the expansion valve, or the distributor.
- Check to see that the system is properly charged and that the liquid line sight glass shows no bubbles. The refrigerant on an undercharged system can migrate to the coldest condenser on the “off cycle”, causing the receiver to lose its liquid seal.

#### 4.5 The Pool Water Is Too Cold

This section applies to Desert Aire dehumidifiers with the pool water heating option. If the pool water requires heating, the standard controller will command the dehumidifier to heat the water. If the dehumidifier cannot heat the pool, due to inadequate water flow or no demand for dehumidification, the water temperature will drop slightly. The controller will then energize the auxiliary water heater, if one has been installed. See *Section 5.5* in the Appendix for more details. If the problem is not controller-related, check the following:

- Make sure that the refrigeration circuit containing the pool water condenser has not locked out on a safety trip.
- Check the “Pool Water Flow” indicator on the controller display panel (for dehumidifiers with the standard controller). The fault indicator will flash if the water flow proving switch does not sense water flow. When this happens, the dehumidifier will not run in the pool water heating mode. All other modes will operate normally. The fault indicator will automatically stop flashing when the problem has been corrected.
- Temporarily raise the pool water heating set point to verify that the auxiliary pool heater energizes on call for second stage pool heat.

- Remove the “air/water priority” jumper from the electrical panel on the dehumidifier. See the wiring schematics and *Section 5.5* in the Appendix for details.
- Make sure that the water filters are not clogged.
- Verify that the water condenser and pool water lines are free of fouling and scaling.
- Check that all service valves and solenoid valves in the liquid line are energized or fully open.
- Verify that there are no restrictions or debris in the liquid line solenoid, the filter/drier, the expansion valve, or the distributor.

## 5. Appendix

### 5.1 Compressor Failure

Although most compressors fail because they are mechanically flawed, most failures are due to system-related problems. Compressor failure can be caused by liquid flood back, air or moisture in the refrigeration system, solid contaminants, excessive heat or electrical service malfunctions. To avoid repeated callbacks, you must determine the cause of the failure and then correct it.

If the compressor has failed because its motor has burned out, the refrigerant, oil, and piping may have become severely contaminated. If a burnout has occurred, use the following procedure to replace the compressor and clean the refrigerant system. Use an oil test kit to determine the severity of the burnout. Make sure you use rubber gloves and eye protection, as contaminated refrigerant and oil can cause severe burns!

## CAUTION

**You must clean the system thoroughly to prevent repeated compressor burnouts.**

#### 5.1.1 Compressor Replacement

Desert Aire dehumidifiers are designed with scroll compressors. Scroll compressors are known for operating more reliably than other compressors in air conditioning and dehumidification applications due to their ability to cope with occasional periods of liquid refrigerant return. There are fewer moving parts in a scroll compressor subject to wear compared to alternative compressor designs. Nonetheless, there are still many mechanical and electrical parts with close tolerances. Replacement of the compressor may be required during the normal service life of the dehumidifier.

#### Inspection and Initial Diagnosis

Generally, the compressor will have two basic failure modes, mechanical or electrical. The compressors are a hermetic design, meaning all components, including the motor, are in a sealed shell. It can be very difficult to determine which issue was the root cause of the failure in the field by inspection of the damaged compressor. For example, an initial bearing failure inside the compressor may create debris that contaminates motor windings. High current draw may be related to a bearing issue or a motor winding issue. The initial inspection must be combined with a final analysis of the machine when returned to working order to conform diagnosis.

Specific items should be noted before the replacement to give the best indications of the failure and complete the diagnosis as the new compressor is installed. The following data should be taken to assist in diagnosis:

- Current draw for each leg of power (if the compressor will run and pump).
- High side and low side pressure (if the compressor will run and pump).

- Resistance of each leg to leg on three phase compressor or each leg to neutral on single phase compressors.
- Check of continuity from each leg to ground.
- Review of all system alarms including the relative timing of the alarms and modes of operation.

It is important to note that other components or lines may have been damaged if the compressor has failed. At times the internal damage to a compressor creates extreme levels of vibration before complete failure. Refrigerant lines and connections may be damaged before the compressor stops. Inspect tubing and components of the system before completing the compressor replacement.

### **Compressor Replacement**

- Refrigeration oil must be tested for acid and particulate during any compressor replacement. For the initial testing, the compressor sump should be used to sample the oil. Oil can be recovered through the Schrader port on the low point compressor shell or through the suction line connection after the compressor has been removed.
- Use Virginia KMP, New-Calgon Phase III, Sporlan Test-All, or equivalent oil test where oil is sampled into a container. Vapor sampling methods may not show particulate and should not be used.
- Read the oil test kit manufacturer's instructions to determine if there is acid present in the oil. Determine if there are other contaminants by viewing the samples for darkness, cloudiness, or particulate.

The following procedures must be used depending on the results of the test above:

### **Any Compressor Service**

- A new filter dryer must be installed when the system has been opened. See *Section 5.6* for component replacement. If there is no acid or particulates indicated, the new compressor can be installed and run. Proceed to Testing and Final Diagnosis.

### **Acid Indicated**

- Install a suction line filter shell and charcoal activated core such as Sporlan or Emerson HH core type or equivalent. The acid levels will be monitored and several core changes may be required. Install ball valves on either side of the suction filter to facilitate these changes. Note that larger Desert Aire systems will have suction filter shells installed from the factory. The shell can be used with charcoal activated cores. Note that a "safety screen" may be required with some manufacturer's cores to prevent small pieces of the core from dislodging and finding their way to the compressor. Follow filter shell and core manufacturer's instructions.
- Review compressor and suction line for area where future oil samples can be taken from the system. If an access fitting exists on the compressor shell below the oil level, no further action is needed. If this is not available, an access fitting can be located at the bottom of a trap in the suction line. Braze in a fitting as required to be able to remove an oil sample.
- Ensure there are access fittings directly upstream and downstream of the suction filter. There is typically one fitting installed on the suction filter. There may be a bulkhead fitting attached to the compressor suction side.

- Do not use acid neutralizing additives or other chemicals for acid removal. The refrigeration system must contain only oil and refrigerant. Precipitates of additives and acids may be considered contamination in the refrigeration system. Other compounds may be present in additives as carriers. Longterm effects of specific additives or compounds with a particular system or design are unknown without significant controlled testing.

### **Particulate Indicated**

- Install a replaceable core liquid line filter shell. Note that larger Desert Aire systems will have replaceable core liquid filter shells installed from the factory. The pressure drop levels will be monitored and several core changes may be required. Install ball valves on either side of the filter shell to facilitate these changes.
- Install a secondary filter such as Sporlan FS-series or equivalent 20 micron filter in the replaceable core.
- Ensure there are access fittings directly upstream and downstream of the liquid filter. There is typically one fitting installed on the filter shell. There is typically one fitting installed on the outlet side of the receiver.

### **Returning to Service**

- See *Section 5.6* for evacuation and charging.
- Restart unit and set unit to run compressors.
- Record the pressure drop across the suction filter and liquid line filter dryer.
- Check sight glass indicator for moisture level.
- Monitor pressure drop across the liquid and suction filters during the first hour of operation. Compare the reading taken earlier. If the pressure differential across the filters is 5 PSI or greater than the initial reading, isolate the filters using the valves installed and recover the refrigerant from the filters. Replace cores. If activated carbon filters were installed in the suction side to remove acid, replace with similar cores. If a secondary filter was installed in the liquid line core to remove particulate, install cores and secondary filter in this location.
- Run unit for 24 hours and review acid levels (if found previously) and pressure differentials.
  - If acid is found, replace with activated charcoal cores and test at 24 hour intervals until acids are at acceptable levels. Once acid is no longer detected, replace cores with standard filter elements. Remove outlet screens if they were required by filter manufacturer.
  - If the pressure differential across the liquid line filter is 5 PSI or greater, replace cores and secondary filter with new components and test at 24 hour intervals until pressure drop is at acceptable levels. Once pressure differential is less than 5 PSI, remove secondary filter and replace cores.

### **Testing and Final Diagnosis**

It is of critical importance to ensure that the system is operating as expected before unit is returned to normal service. Complete a Compressor Replacement Form located in the back of this manual. Validation of this report allows for the continued coverage of the compressor under the original warranty. It is possible that there was an internal defect in the compressor or normal mechanical wear occurred

over time. Compressor longevity generally is a function of load, lubrication, electrical input conditions, and temperatures.

There is a cause for the compressor failures that must be identified before unit is placed back into full service. Both the identification of the cause of compressor failure and the proper cleanup of the system must be addressed to avoid repeat compressor damage.

## 5.2 Recommended Duct Design

You must use proper duct design to ensure that the dehumidifier operates efficiently and without problems. Undersized or restrictive ducts reduce the system airflow, which can cause premature compressor failure. Use the following diagrams as a guide when you design the duct system.




Figure 56 – Recommended Duct Designs for Desert Aire Dehumidifiers



### 5.3 Pool Water Chemistry

Pool chemistry must be maintained to ensure the proper pH, total alkalinity, calcium hardness, and free chlorine, NSPI recommends the following levels for pool chemistry:

- pH: 7.4 – 7.6
- Total Alkalinity: 100 – 150 ppm
- Calcium Hardness: 200 – 250 ppm (Plaster Pool)
- Free Chlorine: 1.0 – 3.0 ppm

Excessive chemical levels in the pool can be dangerous to users and can damage pool hardware, including the dehumidification system. The Desert Aire warranty does not cover equipment damaged by faulty pool chemistry.

### 5.4 Recommended Controller Setting

#### 5.4.1 Controller Set Points

It is important to determine your comfortable set points and to avoid further controller adjustments. It takes time for the unit to establish equilibrium at a given set point. Therefore, continued set point adjustments will lead to high energy consumption and user discomfort. Continuous blower operation is recommended. This will reduce air stratification and assure that the refrigeration circuit is activated only when it is necessary.

#### RECOMMENDED SET POINTS:

- Humidity: 50% to 60 % RH
- Air Temperature: 2° to 4° F above the pool water temperature

### WARNING

**Never disable a dehumidifier in a pool room application unless the pool has been drained. Even when not in use, pool water continues to evaporate adding moisture to the air. During these periods of high humidity, moisture will seep into walls, ceilings, furniture, etc. Although the dehumidifier may be capable of regaining control of pool room conditions after re-start, in the long run, moisture damage to the pool room will become apparent.**

### 5.5 System Operating Modes

The standard sequence of operation of a Desert Aire dehumidifier is relatively simple to understand. Note that the sequence may vary depending on which condenser options have been purchased and installed.

#### 5.5.1 Basic Sequence

The compressor is designed to start on a call for cooling or dehumidification. As the refrigerant flows through the evaporators, it absorbs a great deal of heat from the airstream. This heat can either be rejected to the air, the pool, or to a remote condenser, depending on

which needs to be reheated.

- If neither the air (such as when in cooling mode) nor the water needs heat, it will be rejected to the remote outdoor condenser.
- If no outdoor condenser is available, the compressor will shut off rather than overhaul the room air. Although the system cannot dehumidify the air when its compressors are off, overheating the space is unacceptable because it will cause occupant discomfort.
- For this same reason, the compressor can start and run on a call for air cooling if another heat sink is available.

The Desert Aire SP senses the temperature and relative humidity of the air entering the evaporator and uses this data to determine the unit mode of operation.

The modes of operation are unoccupied, occupied, event, max outside air and purge mode.

- **Unoccupied Mode**

In the Unoccupied mode, typically outdoor air dampers will be closed and a very small amount of exhaust air is extracted from the building in order to ensure the space is negatively pressurized. When a Low Exhaust option is selected, the Unoccupied mode can be configured to bring in low flow rate of outdoor air in order to offset any amount of exhaust that may be extracted from this separate system. Unoccupied mode is engaged when no other mode is presently engaged.

- **Occupied Mode**

This mode is used when a typical amount of occupancy in the space is to be encountered. Occupancy can be commanded with any of the following: Internal Occupancy Schedule via an integral seven-day programmable time clock, a contact closure, or through a Building Management System (BMS) network.

- **Event Mode**

This mode is typically used to signal the unit to bring in greater amounts of outdoor air when spectators are expected to be present. The mode can be activated through a dry contact closure or Building Management System (BMS) network. Note that the Occupied mode must be engaged when Event mode is commanded or no change will occur.

- **Max OA Mode**

Max OA mode is typically used to signal the unit to bring in a very high level of outdoor air under specific circumstances. The economizer feature includes outdoor sensors to monitor the OA condition. When the outdoor conditions are appropriate; to reduce the temperature and/or humidity, the unit will index to MAX OA mode automatically. Additionally, if equipped with a VOC monitor option, and the VOC reading from the sensor exceeds the set point, the unit will index to Max

OA mode. The mode can be activated programmatically as described above or through the Building Management System (BMS) network.

- **Purge Mode**

Purge mode is used to clear airborne byproducts of the pool disinfection process as required by the operator. This is typically done when the space is not occupied. When the need is determined, a signal is given via a contact closure or through the Building Management System (BMS) network. The unit will bring in the specified amount of outdoor air (typically at a very high flow rate). During purge mode the refrigeration system is disabled. The heating system is controlled from the supply air temperature sensor only and the system is set to a point that only avoids major condensation from occurring at the ducts and diffusers. In this way, the energy required to clear the air of these byproducts is minimized while avoiding issues with introducing very cold air.

In all modes the unit monitors the static pressure of the zone and modulates the exhaust airflow rate to maintain the set point. Typically this is set to -0.050" WC. This means that the exhaust air flow rate will be greater than the outdoor air flow rate to maintain this negative static pressure. Building envelopes that are leaky may require much more exhaust air than outdoor air. The amount of outdoor air in each mode may be limited through the controls if desired, but the space must be kept at a negative static pressure in order to avoid mold and property damage.

Note that condensation may occur when cold outdoor air is mixed with warm, humid return air inside the dehumidifier. During the winter months, this moisture can freeze and cause serious damage to the equipment. Desert Aire dehumidifiers are equipped with an internal temperature sensor which will close the outdoor air damper if senses freezing temperatures inside the unit.

If outdoor temperatures in your area drop below 32°F, and outdoor air code compliance is required at all times, you may need to install an optional preheating coil. System failures caused by improper outdoor air duct installations are not covered by the Desert Aire warranty.

The intake mounted sensor (if sensor installed in the unit) or the zone sensor determines the current temperature and RH of the space.

### **5.5.2 Blower Operation**

The following is the blower control sequence for the standard SP control system:

- The SP unit will run to achieve a constant supply airflow as initially programmed in the unit controller per order specifications. Measurement through the included supply and exhaust blower's venturi is used for this automatic operation.
- The exhaust fans will run to achieve a negative static pressure in the zone. This airflow rate can be read on the CM3560 controller display.

- If a Desert Aire RecoverAire (ER) unit is supplied, the SelectAire Plus will command the ER unit to flow the appropriate airflow in the ER unit.

### **5.5.3 Dehumidifier Operation**

The SelectAire Plus offers customized dehumidification to the pool space by dedicating a smaller circuit to sensible heat exchanger and a larger circuit to cover latent heat exchange. The latent enhanced circuit includes a 100% passive wrap around heat pipe assembly. In the latent circuit the heat-pipe wraps around the DX evaporator. Connecting refrigerant piping in or out of the heat-pipe is not required so is a completely isolated system. It offers “free” pre-evaporator cooling and post evaporator heating without the use of expensive electrical resources. The heat pipe pre-cools and post-heats the airstream to allow the evaporator to maximize the moisture removal content. This allows for the most efficient means of removing moisture from the air stream.

Dehumidification mode is activated when the intake air has a relatively low sensible load, but a high latent load. In dehumidification mode the latent circuit (Circuit B) will initiate to meet the dry bulb temperature and relative humidity setting that is commanded by the CM3560 controller. This is called the first stage of dehumidification. If running Circuit B alone does not satisfy this relative humidity requirement the second sensible circuit (Circuit A) will come on line to meet the requirement. This is called the second stage of dehumidification.

### **5.5.4 Cooling Operation**

Cooling mode and stages are enabled as the temperature within the space rises. In cooling mode, Circuit A is the first stage and Circuit B is the second stage. If equipped with a co-axial pool water heater, heat is rejected to the pool water if pool heating is required. If the pool temperature is satisfied, the heat is rejected to a cooling condenser (if equipped).

### **5.5.5 RecoverAire (ER) Energy Recovery Operation**

The SP unit will work in conjunction with a Desert Aire ER unit or similar type energy recovery unit. Energy recovery is performed in the first stage of heating when the unit is set to occupied mode. Secondly, Circuit A will start in reheat mode. Air will be directed to the exhaust airstream after flowing through the evaporator, except for when the second stage of Dehumidification is active. This recovers energy to the refrigeration circuit that can be used to heat outdoor air.

### **5.5.6 Damper Operation**

The SP uses strategic damper operation and positioning to maximize airflow efficiency through the SP cabinet. The dampers function as outlined below.

#### **5.5.6.1 Outdoor Air and Outside Air Bypass Dampers**

The Outdoor Air damper will open when there is a call for outdoor air. The Outdoor Air Bypass Damper will modulate automatically to maintain the outdoor air CFM.

#### **5.5.6.2 Evaporator Bypass and Thru Dampers**

When the compressors are on, the evaporator air pressure differential will determine if airflow is properly programmed in factory settings. The evaporator bypass damper will modulate to achieve this programmed setting.

In certain modes of operation the Evaporator Thru damper will modulate. This damper will modulate to maintain the pressure drop across the Circuit A evaporator.

#### **5.5.6.3 Exhaust Dampers**

The exhaust dampers will open and close depending on the requirement for exhaust air. There are two types of exhaust: warm and cool. The cool exhaust damper works in conjunction with the Evaporator Thru damper to achieve energy recovery. The warm exhaust opens when no energy recovery is needed or a very high level of exhaust air is required.

### **5.5.7 Examples of Cooling and Dehumidification Operation**

The following are examples of how the unit will be expected to operate in the typical loads encountered. Note that there are many variables in conditions and unit sizing. These are included to give basic understanding of the expected operation.

#### **Ambient Condition Cool and Humid (Typical Spring Day)**

Unit will be primarily in dehumidification mode and may cycle in 1st and 2nd stages of dehumidification. In hot gas reheat coil will be active most times. The unit may occasionally shift to cooling mode on one or both circuits, especially during mid-day when the solar load is high. During the night-time hours when the unit is unoccupied and ambient starts to cool, the unit will be in dehumidification mode less frequently and auxiliary heating may become active.

#### **Ambient Condition Hot and Humid (Typical Summer Day)**

Unit will be primarily in dehumidification mode and cooling active. The remote condenser will be active most times. The unit may occasionally shift to dehumidification mode on one circuit, especially as the solar load starts to decrease in the afternoon. During the night-time hours when the unit is unoccupied and ambient starts to cool, the unit will be in cooling mode less frequently and more frequently in dehumidification.

#### **Ambient Condition Hot and Dry (Typical Early Fall Day)**

Unit will be primarily in cooling mode with one or two circuits active. Depending on the load one or both of the circuits may cycle on and off to maintain condition. During the night-time hours when the unit is unoccupied and ambient starts to cool, the unit will be in cooling mode less frequently and auxiliary heating may become active.

#### **Ambient Condition Cold and Dry (Typical Winter Day)**

If the unit is equipped with exhaust energy recovery, and the controller senses the zone dehumidified temperature within the space is dropping, it will shift to energy recovery mode.

This will energize the Circuit A compressor(s) and open the cool exhaust damper. This energy recovery can be considered the first stage of heating and will occur before the auxiliary heating is activated.

During the daytime the unit may occasionally be in dehumidification mode. Energy recovery will index on as required and auxiliary heating will become active as required to maintain space conditions.

Note that it is not uncommon for the unit to occasionally shift into cooling mode in the wintertime when the solar load is high and the envelope contains a high number of south facing windows. This can occur down to 30°F or even lower in some areas.

Note that in extreme cool and dry conditions when in occupied mode the outdoor air may dry the space significantly. When this is the case, the exhaust air may no longer have the energy to recover. The unit controls will disable the energy recovery mode when this occurs if the unit is equipped with this option.

### **5.5.8 Heating Operation**

#### **Auxiliary Heating**

The SP offers three types of auxiliary heaters: Gas, Electric and Hot Water Heaters.

Gas Heaters use the combustion of natural gas or liquid petroleum (lp) gas to create a heat source over tubes. Air passes over these tubes and the warmth from the tubes is exchanged into the air. Electric heaters use the same method but instead of using the combustion process electrically heated elements make contact with the air to warm it. Lastly, hot water coils use a tube and fin arrangement. Supplied hot water is pumped through the tubes. The tubes transfer heat to the perpendicular fins and the air passing through absorbs the heat from both the tubes and fins.

Ensure that the supply air temperature sensor is downstream of any fluid installed auxiliary heaters. The pre-programmed values for the deadbands, differentials, and PID values are expected to create a good balance between temperature control and stability in the typical applications. Occasionally the heater may have larger or smaller capacity relative to the space or sensor placement location. If space conditions vary greatly or frequent cycling between modes are apparent, the values may need to be changed. Modification to the parameters and tuning should be done with care. If it is determined that a specific application would benefit from modification, time and patience will be required to ensure that the desired effect is achieved.

#### **Staged Heating**

When installed in a relatively mild climate with minimal outdoor air requirements, there is a relatively small amount of heating capacity. In these cases, staged heating is a cost effective and simple method.

The auxiliary heating outputs come set from the factory for control of staged control or modulating control as specified at the time of order. When set for Staged, the dry contact associated with the heating output will close on a drop in temperature of the zone set point minus the deadband minus the differential. The contact will remain closed until the temperature reaches the zone set point minus the differential.

Heater On = Zone Set Point – Heating Deadband – Heating Differential

Heater Off = Zone Set Point – Heating Deadband

Example:

- Zone Set Point: 85°F
- Heating Deadband: 2°F
- Heating Differential: 1°F

In this example, the heater output will close at 82°F and will open at 83°F. Due to some system capacitance and sensor hysteresis, the actual zone condition may overshoot these values slightly, but should not overshoot these values to cause the unit to shift into a cooling mode. Should the heater be very oversized and the overshoot significant, it may be necessary to increase the deadband to prevent cycling between modes.

It should be noted that the nature of the staged heating will create a significant variation in the supply air temperature as the heater is turned on and off. Heaters are sized for extreme conditions (typically the 99th percentile heating capacity). At many times of the year the heater is essentially oversized. Depending on the location of the supply ducts and diffuser configurations, the variations may create drafts within the space. Also, if the air temperature is very low and the heater cycles off, the supply air temperature may be lower than the space dew point. This would cause condensation on ducts, diffusers, and surfaces.

Should there be issues with supply temperature variations, modulating heat should be considered.

### **Modulating Heating**

When the application has a moderate to extreme climate and outdoor air is specified, it is recommended that auxiliary heating be modulating.

When the controls are set for Modulating heat output, both the binary heat output contact and the modulating heat output are active. The binary heat output acts as an enable contact that can activate a gas heater enable signal or start a hot water coil pump system. The modulating output is intended to vary the gas valve, SCR electric heater, or hot water coil water flow rate.

The modulating heating sequence works based on a Zone Reset of the Supply Air Temperature. When the zone temperature decreases to the Zone Temperature minus the Heating Deadband, the controller enables heating mode and starts to increase the calculated

Supply Air Temperature Set Point. The heater output will modulate to maintain the calculated Supply Air Temperature Set Point. The heating mode is always disabled if the zone exceeds the Zone Temperature Set Point. Resetting the supply air temperature in heating not only closely maintains the zone temperatures, but helps ensure the supply air temperature is held to minimum values. The default values used for the zone PID, supply air PID, and deadband are appropriate for most applications and heater sizes. Should the command for Supply Air Temperature change too quickly, the PID action for the reset can be slowed by increasing the tuning values. Should the heater not be able to closely maintain the calculated Supply Air Temperature Set Point, the values for the heater output loop can be adjusted.

Heater Enabled = Zone = Zone Set Point = Heating Deadband

Heater Disabled = Heat Output PID Loop < 5% or Zone = Zone Set Point

Example:

- Zone Set Point: 85°F
- Heating Deadband: 2°F

In this example, the binary heater contact will close at 83°F and the analog output will start to increase. The PID loop will modulate to maintain the zone at the 83°F temperature. Should the analog signal for heat decrease to less than 5%, the binary contact will open. In addition, if the zone is sensed at greater than 85°F at any point, the contact will open, limiting heater overshoot due to poorly tuned loop.

#### **5.5.9 Suction Pressure Operation**

The low suction pressure alarm and trip protects the SP unit. Whenever the suction pressure in either circuit falls below 58 psig, the unit compressors will shut off with an alarm indication. The compressors will be allowed to restart when the suction pressure rises to above 106 psig. Note that the compressors will be off for at least 5 minutes on the recycle timer.

If the low suction pressure cycle occurs 3 (adjustable) times in a 1 (adjustable) hour time period, then an alarm will be indicated and recorded in the alarm history as a multiple suction pressure alarm.

### **5.6 Component Replacement, Charge, Evacuation, & Leak Instructions**

Note that a new liquid line filter dryer will be required any time a refrigeration system is opened for servicing. New dryer should be of the same capacity as the original or larger.

#### **Recovery**

When there has not been a major refrigeration system leak, the system will contain refrigerant. This refrigerant must be either recovered to separate cylinders appropriate for the refrigerant type or isolated in a portion of the refrigeration system that will not be open for service. In all cases you must comply with *Section 608 Refrigerant Recycling Rule of the Clean Air Act*.



## **Recovery of Systems with a Refrigeration System Leak**

As much refrigerant as possible must be recovered into separate refrigerant cylinders appropriate for the refrigerant being serviced. System pressure near the leak site should be monitored closely to ensure this area is not pulled to a vacuum. Isolated sections of the system as required and recover independently to avoid refrigerant contamination. Uncontaminated refrigerant can be reused in the refrigeration system it was recovered from.

## **Recovery of Systems without a Leak**

Systems that do not have leaks, but still require refrigeration system service, may have charge isolated in condensers if these particular components do not require direct service.

Desert Aire dehumidifiers have different receiver sizes depending on the model and size. Condenser sizes and configurations may also vary. In general, larger receivers will come equipped with isolation valves that will allow for a portion of the charge to be contained in the receiver during servicing. Unit equipped with the remote condensers will have isolation valves located inside the unit cabinet near the area where the connections are made.

The compressor can be used to move refrigerant to the system components that will be used to temporarily hold the charge. Note that cooling a condenser by running as many fans as possible and/or cooling the coil surface with a stream of water can assist in storing charge.

The low side pressure should be monitored closely while using this procedure to store charge. Under no circumstances should a compressor be allowed to run in a vacuum. When most of the refrigerant is isolated in the condensers, recover remaining charge into separate refrigerant cylinders appropriate for the refrigerant being serviced. Carefully track the amount of refrigerant charge removed as this exact amount should be placed into the units when recharging.

## **Repair / Component Replacement**

- If any portion of the system was at a vacuum, place dry nitrogen in the system until atmospheric pressure is reached.
- It is preferred that components are removed by heating the braze to the re-melt temperature and mechanically moving the component. When this is not possible due to proximity of cabinet structure or other components, a tubing cutter can be used to remove sections of piping. Where new tube is required for replacement, use dehydrated tube where possible. Use the same type of fittings as original. Route the pipe in the exact manner as originally routed.
- Use Type K per ASTM B 88 or ASTM B 819 or Type ACR per ASTM B 280 copper tubing or for all tubes 1-1/8" and smaller.
- Tubes 1-3/8" and larger shall use Type K per ASTM B 88 or ASTM B 819.
- Cap sections of tube and components that are not actively being installed to prevent infiltration of moisture and contaminants.
- Use only braze alloy to join tube
  - The selection of filler metals is highly dependent on the tube fit, clearance, and operator preference for flow. When flux is to be used, care should be taken to

ensure that the flux is not introduced to the inside of the tube. It is recommended that phosphorous bearing alloys be considered for copper to copper connections due to their self-fluxing on copper to copper joints. Refer to alloy manufacturer's guidelines for details on compatibility.

- Flow nitrogen into tubing to prevent the formation of copper oxides.
  - Copper oxides form rapidly when copper is heated to temperatures required by the brazing process and exposed to oxygen in the air. Copper oxides flake easily on the inside of the tubing and dislodge easily when the system is filled with refrigerant and oil. The particulate can move throughout the system and cause contamination on valves and other critical components. System filters may become fouled.
  - Flowing nitrogen into the system and ensuring that the inside of the tube is significantly free from oxygen while brazing ensures that oxides do not form. As the last joints of a system are made, additional thought must be made on the location where the nitrogen can escape. Schrader valves are placed throughout the system. These valves can be opened to allow for nitrogen to flow without generating pressure behind the braze joint that is being created.
- See *section 5.1.1* for special procedures related to compressor replacements
- Replace liquid line filter dryer as last step in system repair. Note that the dryer will readily absorb moisture from the ambient air and must be open only for as long as required for installation.
- After completion of all repairs, pressure test system using nitrogen pressure decay test or nitrogen with tracer gas and appropriate leak detector.

## Evacuation

- Carefully inspect pump and related equipment before connecting to system. Ensuring gaskets are in good condition and pump is capable of low vacuum levels can save time. Connect pump(s) to as many locations as possible ensuring all locations are well sealed. If a field charge will be required, connecting a refrigerant tank to the system with a good valve is recommended. Any hose connections requiring purging of non-condensable can be done at this point.
- Evacuate the line to 400 microns measure at a point on the system furthest away from the pump.
  - Note that a gauge installed on the pump or in close proximity will give a lower reading while the unit is being evacuated.
  - A deep vacuum gauge should be used to evaluate the pressure. Compound manifold gauges do not allow for enough accuracy at the pressures required.
  - The system should be able to hold a vacuum under 500 microns for more than 10 minutes.
  - If pressure continuously rises at a rapid rate, there is likely a system leak. Review all piping connections and correct before continuing evacuation.
  - Pressure rising above 500 microns and tending to stabilize at a higher pressure indicates the system has moisture above specifications. Continue evacuation until 500 microns or lower can be held for a minimum of 10 minutes.

### **Alternative Evacuation Specified by Process**

After components have been repaired or replaced evacuation procedure should take place. Very small amounts of refrigerant may still be mixed with the oil in the system. Out-gassing of this refrigerant may interfere with the evacuation and vacuum decay testing.

**IF, AND ONLY IF**, a unit has been previously charged with refrigerant, and standard evacuation method has not been successful after 24 hours minimum using the standard procedure, the following alternative method should be used.

1. Check vacuum level. It should be a maximum of 1,500 microns absolute pressure. If this is not the case, review system for leaks and continue evacuation process until 1,500 microns is achieved.
2. Purge system with nitrogen to atmospheric pressure (0 gauge pressure). Ensure all portions of system are at this pressure. Seal system and wait 10 minutes.
3. Start vacuum pump and draw system to 1,500 microns or less.
4. Purge system with nitrogen to atmospheric pressure (0 gauge pressure). Ensure all portions of systems are at this pressure. Seal system and wait 10 minutes.
5. Start vacuum pump and draw system to 500 microns. Seal system. System may rise to higher level, but should not rise above 1,000 microns in 10 minutes timeframe.  
If unsuccessful, continue evacuation or check for leaks.

It is anticipated that the system was clean and tight from the original process and refrigerant only is mixed with oil. Alternative process should not be considered if there is chance of free water entering the system or the system was open for any significant time.

### **Charging**

- Charge should be weighed into the system using a scale. In cases where the full charge was recovered, weigh in the charge with the recovered refrigerant and add the appropriate amount to meet the rating plate and field charge (if applicable). This should be placed in the high side of the system at the receiver.
- In cases where the full charge cannot be added to the system high side, the charge can be added to the low side of the system only when compressors are energized. If this is required, the compressors should be energized and the charge should be slowly metered into the suction line as far as possible upstream of the compressor. If the unit is equipped with an accumulator, the charge needs to be added to the port upstream of this location. The bulkhead fittings on the side of the unit should not be used for charge addition. Monitor superheat at the compressor suction inlet using the bulkhead fitting and a temperature sensor on the suction line near the compressor. Superheat should not drop below 10 degrees during the process of adding charge.

## Testing and Final Diagnosis

Check the oil level in the compressor after the system has been running for 24 hours. Oil may have been contaminated in the liquid refrigerant when recovered from the system. Most of this oil will be returned if the recovered refrigerant is used. If new refrigerant is added, additional oil should be added based on the following ratio:

$$\text{New Refrigerant Charge Added, lbs.} \times 0.352 = \text{Oil charge, oz.}$$

It is of critical importance to ensure that the system is operating as expected before the unit is returned to normal service. Test component replaced and function of the system. Many times a separate component in the system may have set a condition that causes a failure of another. Thoroughly test systems to ensure repeat failures do not occur.

## 5.7 System Rating Plate

The system rating plate is attached near the electrical enclosure of the dehumidifier. Figure 57 is an example of this rating plate.


<b>Model No:</b> SPXXXXXXEXXXXX <b>Serial No.</b> XXXXXXXXX																																																		
<b>Voltage/Phase/Hz:</b> ### / # / ## <b>Control Voltage</b> ##		<b>Minimum Ampacity</b> ### <b>Maximum Overcurrent Protection Device</b> ### <b>Minimum Disconnect Current Rating</b> ###																																																
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="3">Compressors</th></tr> <tr> <th>Mtr#</th><th>RLA</th><th>LRA</th></tr> <tr><td>#</td><td>#</td><td>#</td></tr> <tr><td>#</td><td>#</td><td>#</td></tr> <tr><td>#</td><td>#</td><td>#</td></tr> <tr><td>#</td><td>#</td><td>#</td></tr> </table>		Compressors			Mtr#	RLA	LRA	#	#	#	#	#	#	#	#	#	#	#	#	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="3">Supply Blowers</th></tr> <tr> <th>Qty</th><th>HP</th><th>FLA</th></tr> <tr><td>#</td><td>##</td><td>##</td></tr> </table>		Supply Blowers			Qty	HP	FLA	#	##	##	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">Transformers</th></tr> <tr> <th>Xfmr #</th><th>VA</th></tr> <tr><td>1</td><td>###</td></tr> <tr><td>2</td><td>###</td></tr> <tr><td>3</td><td>###</td></tr> <tr><td>4</td><td>###</td></tr> <tr><td>5</td><td>###</td></tr> <tr><td>6</td><td>###</td></tr> <tr><td>7</td><td>###</td></tr> </table>		Transformers		Xfmr #	VA	1	###	2	###	3	###	4	###	5	###	6	###	7	###
Compressors																																																		
Mtr#	RLA	LRA																																																
#	#	#																																																
#	#	#																																																
#	#	#																																																
#	#	#																																																
Supply Blowers																																																		
Qty	HP	FLA																																																
#	##	##																																																
Transformers																																																		
Xfmr #	VA																																																	
1	###																																																	
2	###																																																	
3	###																																																	
4	###																																																	
5	###																																																	
6	###																																																	
7	###																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="3">Condenser Fans</th></tr> <tr> <th>Qty</th><th>HP</th><th>FLA</th></tr> <tr><td>#</td><td>##</td><td>##</td></tr> </table>		Condenser Fans			Qty	HP	FLA	#	##	##	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="3">Exhaust Blowers</th></tr> <tr> <th>Qty</th><th>HP</th><th>FLA</th></tr> <tr><td>#</td><td>##</td><td>##</td></tr> </table>		Exhaust Blowers			Qty	HP	FLA	#	##	##	Motors powered by VFDs or 3 phase transformers use line-side current for MCA/MOPD calculation. Load-side FLA shown per UL 1995.																												
Condenser Fans																																																		
Qty	HP	FLA																																																
#	##	##																																																
Exhaust Blowers																																																		
Qty	HP	FLA																																																
#	##	##																																																
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="3">Heat Wheel Motor</th></tr> <tr> <th>Mtr#</th><th>HP</th><th>FLA</th></tr> <tr><td>#</td><td>##</td><td>##</td></tr> </table>		Heat Wheel Motor			Mtr#	HP	FLA	#	##	##	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="4">Electric Heater(s)</th></tr> <tr> <th>kW</th><th>##</th><th>FLA</th><th>##</th></tr> <tr><td>kW</td><td>##</td><td>FLA</td><td>##</td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> </table>		Electric Heater(s)				kW	##	FLA	##	kW	##	FLA	##																										
Heat Wheel Motor																																																		
Mtr#	HP	FLA																																																
#	##	##																																																
Electric Heater(s)																																																		
kW	##	FLA	##																																															
kW	##	FLA	##																																															
This Unit is for Outdoor Use																																																		
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">Maximum Design Pressure (psig):</th></tr> <tr> <td>650 High Side</td><td>250 Low Side</td></tr> </table>		Maximum Design Pressure (psig):		650 High Side	250 Low Side	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">Wiring Diagrams:</th></tr> <tr> <td>XXXXX-HV1, XXXXX-HV2, XXXXX-LV1, XXXXX-LV2, XXXXX-LV3, XXXXX-LV4</td><td> </td></tr> </table>				Wiring Diagrams:		XXXXX-HV1, XXXXX-HV2, XXXXX-LV1, XXXXX-LV2, XXXXX-LV3, XXXXX-LV4																																						
Maximum Design Pressure (psig):																																																		
650 High Side	250 Low Side																																																	
Wiring Diagrams:																																																		
XXXXX-HV1, XXXXX-HV2, XXXXX-LV1, XXXXX-LV2, XXXXX-LV3, XXXXX-LV4																																																		
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="4">R-410A Factory Charge lbs.</th></tr> <tr> <td>Circuit A</td><td>###</td><td>Circuit B</td><td>###</td></tr> </table>		R-410A Factory Charge lbs.				Circuit A	###	Circuit B	###																																									
R-410A Factory Charge lbs.																																																		
Circuit A	###	Circuit B	###																																															
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="6">Independent Powered Electric Heater</th></tr> <tr> <td colspan="2">Voltage/Phase/Hz: ### / # / ##</td> <td colspan="2">Minimum Ampacity</td> <td colspan="2">###</td></tr> <tr> <td colspan="2">Control Voltage ##</td> <td colspan="2">Maximum Overcurrent Protection Device</td> <td colspan="2">###</td></tr> </table>						Independent Powered Electric Heater						Voltage/Phase/Hz: ### / # / ##		Minimum Ampacity		###		Control Voltage ##		Maximum Overcurrent Protection Device		###																												
Independent Powered Electric Heater																																																		
Voltage/Phase/Hz: ### / # / ##		Minimum Ampacity		###																																														
Control Voltage ##		Maximum Overcurrent Protection Device		###																																														

Figure 57 – SP Dehumidifier Rating Plate

## **5.8 Start-Up Supervision Supplemental Information**

A Desert Aire factory start-up is an option which is normally purchased with the equipment. A factory start-up includes several key services:

- The expertise of an accomplished, factory-trained mechanic who will supervise the commissioning of the equipment.
- This Desert Aire representative will assist the installing contractor with filling out the Start-Up Report.
- He will also inspect the installation to make sure that the dehumidifier has been properly integrated with the rest of the equipment on the jobsite.
- Finally, he can train the maintenance personnel to operate and service the equipment if necessary.

A factory start-up does not include installation assistance. The installing contractor is responsible for ensuring that the system is ready for start-up when the Desert Aire representative arrives.

When the installing contractor is confident the system will be ready, he should contact the Desert Aire Sales representative to schedule the start-up. Please call at least two weeks before the desired start-up date to help prevent scheduling conflicts.



## LC/LV/SA/SP Start-up Request

**Factory Assisted Start-Up** consists of a Desert Aire Service Department Technician to visit the job-site and provide supervisory experience to installing contractors as they perform the required procedures as outlined in our warranty activation start-up report. The company technician will also present an educational review of the dehumidifier's operating and maintenance requirements. **Factory Assisted Start-Up is not an installation bid & therefore the system must be ready to run before scheduling.**

**CST Start-Up** is performed by a local Certified Service Technician who has been trained by Desert Aire. The CST performs all duties listed above. In addition, they will supply the "items to be supplied for start-up" as listed below. Please note charges for refrigerant will apply if refrigerant is necessary to complete the start up.

**Items to be completed by the installing contractor before any Start-Up can be scheduled:**

- ☐ Dehumidifier leak checked and inspected for internal concealed damage – remove access panels and inspect the interior of the unit for transit damage. Contact Desert Aire immediately if damage is noted **(262) 946-7400**
- ☐ Dehumidifier leveled and properly supported per the installation manuals recommendations. **See section 2.1 of the Unit I&O manual for details**
- ☐ Outside air duct filters and damper installed (if applicable) – **See LC/LV/SA/SP I&O manual section 2.2 for details**
- ☐ Condensate P Trap installed with heat trace for winter operation. **See LC/LV/SA/SP I&O manual section 2.3 for details**
- ☐ Remote condenser plumbed per Air Cooled I&O manual sections 2.3 and 2.4, check valve installed in the hot gas Discharge line **(this valve is shipped separately with other controls)**, leak checked, evacuated, and charged if necessary. LC and LV Units require additional field charging. **Refer to the charge label affixed to the unit for details.** Refrigerant added \_\_\_\_lbs. (if applicable)
- ☐ Gas heater lines plumbed and purged / Record gas pressure entering the unit - \_\_\_\_\_'wc (if applicable)
- ☐ Refrigeration line set is clamped and the header supported per the **Air Cooled I&O manual sec 2.3**
- ☐ Pressure transducer and cord sent with the remote condenser installed on the liquid line header and wired to the Johnson 450 controller. **See section 2.7 of the Air Cooled I&O manual for wiring details.** (if applicable)
- ☐ All electrical connections terminated and verified for proper voltage at the unit and the condenser (if applicable)
- ☐ All field controls, sensors - duct or wall sensor installed per the **LC/LV I&O manual Section 2.7 or SA/SP I&O manual Section 2.8**, (This sensor is shipped separately with other components) actuators installed and circuits verified that they are wired correctly. If you have questions, contact Desert Aire for instructions **(262) 946-7400**.
- ☐ Water condenser circuit connected to dehumidifier with flow meter and balancing valves installed in circuit (if applicable)
- ☐ Water temp sensor well and temp sensor installed per **LC/LV/SA/SP I&O manual section 2.4** (This sensor is shipped separately with other components)
- ☐ Water flow verified and air purged from water the lines. (If applicable)
- ☐ Remove shipping blocks from under the compressor.

**Items to be supplied by the installing contractor (Factory Assisted Start-up only)**

- ☐ Equipped service vehicle and service technician – Technician will be trained.
- ☐ Volt/Amp/OHM meters / Refrigerant Manifold Gauges
- ☐ Combustion Analyzer (SA Units only supplied with factory gas heating option)
- ☐ Air balancing equipment (magnehelic or manometer differential pressure gauge – one-inch scale preferred)
- ☐ 50# of the appropriate refrigerant & scale.
- ☐ Hand pump for adding oil to compressors and 1 gallon of one of the following oils:
  - Copeland Ultra 32-3MAF
  - Lubrizol Emkarate RL32-3MAF Park Emkarate RL32-3MAF
  - Nu Calgon 4314-66 (RL32-3MAF)(This is required on split systems based on line set calculations and trapping)

Unit Information



Model #: \_\_\_\_\_

Serial #: \_\_\_\_\_

Jobsite Information

Job site name: \_\_\_\_\_

Job Site Address: \_\_\_\_\_

\_\_\_\_\_

Contractor Information

Installing Contractor: \_\_\_\_\_

Manager's Name: \_\_\_\_\_ Phone #: \_\_\_\_\_

Job Site Contact: \_\_\_\_\_ Cell #: \_\_\_\_\_

Controls Company Name: \_\_\_\_\_

Controls Contact: \_\_\_\_\_ Cell#: \_\_\_\_\_

Test and Balance Company: \_\_\_\_\_

If you are unable to supply any of the required equipment you must contact Desert Aire before returning this document.

I agree that all of the above has been completed as of \_\_\_\_\_ (Date) If a return trip must be scheduled due to insufficient job-site preparation an additional purchase order must be issued to Desert Aire for re-scheduling. **A two-week minimum is needed to schedule start-up.** Once the form is completed please fax or email both pages to the Desert Aire service department. Fax (262) 946-7400 Email: [service@desert-aire.com](mailto:service@desert-aire.com)

Signature of project manager \_\_\_\_\_ (print)

\_\_\_\_\_ (sign)

Company Name: \_\_\_\_\_ Phone #: \_\_\_\_\_

## **5.9 System Start-Up Report**

A copy of the system “Start-Up Report” can be found on the following pages. This report needs to be filled out thoroughly by a qualified service technician and returned to Desert Aire for warranty validation. Please ensure that the model and serial number of the unit are noted on this form.

The model and serial number can be found on the system’s rating plate located on or near the electrical compartment service door. Failure to complete and return this form will void the unit’s warranty. These reports are also helpful when trying to correct existing problems. Should you need system diagnosis help, fax the completed worksheet to Desert Aire’s Service Department using the number provided. Be sure to include your name and a telephone number when you can be reached.





## SP Series Start-up Report

**Important** – To ensure warranty validation and continued customer satisfaction, complete this form and return it to Desert Aire immediately after start-up. Validation of this report activates the warranty.

**Desert Aire Corporation**  
**c/o Service and Warranty Department**  
**N120W18485 Freistadt Road**  
**Germantown, WI 53022**  
**(800) 443-5276**

---

### Instructions

- **Warning** – Only trained, qualified personnel should install and service Desert Aire equipment. Serious Injury or death can result from improper handling of this equipment. High voltage electrical components and refrigeration under pressure are present.
  - Before continuing, read the Installation and Operations manual. If you do not fully understand the manual contact the Desert Aire Service Department. Please be prepared with the model and serial numbers located on the rating plate of the unit.
  - Use one start up report per unit. Print or type all information. If there is not enough space available for readings or comments please attach additional pages directly to the start- up report.
- 

### Location and Unit Information

Installation Name: \_\_\_\_\_

Installation Address: \_\_\_\_\_

Desert Aire Representative: \_\_\_\_\_

Dehumidifier Model #: \_\_\_\_\_ Serial #: \_\_\_\_\_

Remote Condenser Model #: \_\_\_\_\_ Serial #: \_\_\_\_\_

Form Completed By (Print): \_\_\_\_\_ Signed: \_\_\_\_\_

Company Name: \_\_\_\_\_ Date: \_\_\_\_\_

Company Address: \_\_\_\_\_ Telephone #: (     ) \_\_\_\_\_

\_\_\_\_\_ Fax #: (     ) \_\_\_\_\_

Application (Pool, Spa, Other): \_\_\_\_\_

\* Denotes that this is a model dependent item

### Proper Installation Checklist

<input type="checkbox"/> Installation manual read and understood	<input type="checkbox"/> Tighten all field and factory wiring	<input type="checkbox"/> Open all refrigeration service valves and tighten packing nuts
<input type="checkbox"/> Dehumidifier installed and leveled properly	<input type="checkbox"/> Adjust and tighten blower belts if necessary	<input type="checkbox"/> Check field and factory piping for leaks
<input type="checkbox"/> Condensate drain trapped and primed	<input type="checkbox"/> Check rotation of blowers	<input type="checkbox"/> Inspect air filters. Clean or replace as necessary
<input type="checkbox"/> Verify the power supply matches the rating plate	<input type="checkbox"/> Check rotation of remote condenser fans	<input type="checkbox"/> 120 volt circuit run to heat trace and powered up

### Unit Power Supply Information

Voltage at power block - No motors running	L1-L2	Control Voltage - No Motors running	Transformer 1	VA
	L2-L3		Transformer 2	VA
	L1-L3		Transformer 3	VA

### Cooling Condenser Line Set Installation

Refer to Installation and operation manual for instructions

Line Set Length		Elevation Change	ABOVE / BELOW	
Hot gas line trapped at every riser	Yes / No	Check valve installed in hot gas line at remote condenser	Yes / No	
Line Set pitched in direction of flow	Yes / No	Line Set Clamped per I/O Manual	Yes / No	
Line Sizes	Circuit A		Circuit B	
	Hot Gas		Hot Gas	
	Liquid Return		Liquid Return	
Additional R410A Added	LBS		LBS	
Additional Oil Added	OZS		OZS	
Flush Cycle Enabled	Yes / No		Yes / No	

Cooling Condenser Fan Cycle Controller Settings								
Refer to Installation and Operation Manual for instructions								
SENS	SN-1							
Analog Fan(s)								
OUTA1	SP1	EP1	OSP1	OEP1	I-C1	UR-P1	bND1	SNF1
Relay Fan(s)								
OUTR2	OND2	OFFD2	ONT2	OFT2	SNF2	SENS2	N/A	
OUTR3	OND3	OFFD3	ONT3	OFT3	SNF3	SENS3		
OUTR4	OND4	OFFD4	ONT4	OFT4	SNF4	SENS4		
OUTR5	OND5	OFFD5	ONT5	OFT5	SNF5	SENS5		
OUTR6	OND6	OFFD6	ONT6	OFT6	SNF6	SENS6		
OUTR7	OND7	OFFD7	ONT7	OFT7	SNF7	SENS7		

Air Flow Readings: Refer to Installation and Operations manual for correct balancing procedures.			
Evap A Static Pressure Drop (Cool Thru Damper)	"WC	VOC Setpoint*	ppm
Evap. Static Pressure Drop (Evaporator Bypass Damper)	"WC	VOC as read off the display*	ppm

Airflow Settings: Refer to Installation and Operations manual for correct balancing procedures.					
	Unoccupied	Occupied	Event	Max OA	Purge
Design OA	CFM	CFM	CFM	CFM	CFM
Actual OA	CFM	CFM	CFM	CFM	CFM
OA Setpoint	"WC	"WC	"WC	"WC	"WC
Damper Position	%	%	%	%	%
Design Exhaust	CFM	CFM	CFM	CFM	CFM
Actual Exhaust	CFM	CFM	CFM	CFM	CFM
Low VFD Command	%	%	%	%	%
Supply Blower Command	%	%	%	%	%
Exhaust Blower Command	%	%	%	%	%
Zone Pressurization	"WC	"WC	"WC	"WC	"WC
Return Duct Static Pres	"WC	"WC	"WC	"WC	"WC
Supply Duct Static Pres	"WC	"WC	"WC	"WC	"WC
The following pertains to indoor units only – Readings to be taken in highest CFM mode applicable					
Exhaust Duct Static Pressure	"WC	Outside Air Duct Static Pressure	"WC		
Exhaust Fan Total Static Pressure (Pressure Diff from inlet of fan to the exhaust duct)					"WC

Supply Blower Information				
	Supply Blower 1	Supply Blower 2	Supply Blower 3	Supply Blower 4
Amperage at Design Airflow	L1	L1	L1	L1
	L2	L2	L2	L2
	L3	L3	L3	L3

Exhaust Blower Information*		
	Supply Blower 1	Supply Blower 2
Amperage at Design Airflow	L1	L1
	L2	L2
	L3	L3

\* At Highest Exhaust CFM

Temperature Readings			
Room Air Temperature	°F	Room Relative Humidity	%
Outdoor Air Temperature	°F	Outdoor Relative Humidity	%
Water Temp (main pool)	°F	Water temp (spa or other)*	°F

Exhaust Blower Information*		
	Circuit A	Circuit B
Motor #		
RLA off nameplate	amps	amps
Amperage	L1	L1
	L2	L2
	L3	L3
Head Pressure	Psig	Psig
Suction Pressure	Psig	Psig
Refrigerant Sight Glass Clear	Yes / No	Yes / No
Superheat	°F	°F
Subcooling	°F	°F
Compressor Oil Level Sight Glass (level should be at least 3/4 full at completion of the start-up)	1/2 3/4 F	1/2 3/4 F

Compressors and Refrigeration in Pool Water Mode		
	Circuit A	Circuit B
Head Pressure	Psig	Psig
Suction Pressure	Psig	Psig
Water Inlet Temperature	°F	°F
Water Outlet Temperature	°F	°F

Compressors and Refrigeration in Cooling Mode* (Remote Condenser Active)		
	Circuit A	Circuit B
Head Pressure	Psig	Psig
Suction Pressure	Psig	Psig
Refrigerant Sight Glass Clear	Yes / No	Yes / No
Superheat	°F	°F
Subcooling	°F	°F
Compressor Oil Level Sight Glass (level should be at least 3/4 full at completion of the start-up)	1/2 3/4 F	1/2 3/4 F

Auxiliary Water / Steam Coil Information*				
	Signal	Inlet Temp	Outlet Temp	Discharge Air Temp
Water Coil		°F	°F	°F
Steam Coil		°F	°F	°F
Confirm Freeze Stat Operation				
Valve opens on freeze condition		Yes / No	OA Damper Closes	Yes / No

Auxiliary Electric Heater Information*					
	Signal	L1 Amps	L2 Amps	L3 Amps	Discharge Air Temp
Electric Heater					°F

Building Management System Information*		
Communication Type (circle one)	BACnet MS/TP - BACnet Ethernet - Modbus RTU - Modbus IP Lon - N/A	
BACnet MS/TP	Device Instance	
	MAC Address	Yes / No
	Baud Rate	
BACnet Ethernet	IP Address	
	Netmask	
	Gateway	
Modbus	Baud Rate	
	Address	

Additional Comments: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_



## HM / HD Duct Furnace – Start-up Information and Test Data

Heatco Model No.: \_\_\_\_\_ Serial No.: \_\_\_\_\_ Start-up Date: \_\_\_\_\_

Appliance Mfr.: \_\_\_\_\_ Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

Start-up Contractor: \_\_\_\_\_ Technician: \_\_\_\_\_ Phone: \_\_\_\_\_

Type of Gas: \_\_\_\_\_ Gas Pressure @ Inlet (burners off): \_\_\_\_" w.c. Supply Voltage @ JB: \_\_\_\_\_ VAC

### Operating Set-up Data

#### Low Fire

#### High Fire

Gas Press. @ Train Inlet	_____ " w.c.	_____ " w.c.
Gas Press. @ Burner Manifold	_____ " w.c.	_____ " w.c.
Gas Input Rate	_____ Btuh	_____ Btuh
CO <sub>2</sub> in Flue Gas	_____ %	_____ %
CO in Flue Gas	_____ ppm	_____ ppm
Flue Gas Temp @ Discharge	_____ °F	_____ °F
Temperature Rise	_____ °F	_____ °F

### Operation checklist

#### YES

#### NO

All gas lines & connections checked for leaks	(     )	(     )
Adequate Combustion Air	(     )	(     )
Condensate Drain Lines Installed	(     )	(     )
Any System deficiencies noted	(     )	(     )

Describe: \_\_\_\_\_

### Modulating System Operation:

#### Analog Signal to SSC30

#### VDC to Mod Valve

#### Man. Press.

(If applicable)	Initial Call for heat	_____ VDC	_____ " w.c.
	0 VDC	_____ VDC	_____ " w.c.
	5 VDC	_____ VDC	_____ " w.c.
	10 VDC	_____ VDC	_____ " w.c.

### Burner Start-up Must Be Performed By Qualified Burner Technician

Must be returned to Heatco Inc., 50 Heatco Court, Cartersville, GA 30120

to activate warranty coverage. Enclose lower portion with Installer / User Manual for future service reference.





## SP Compressor Replacement Form

### Location and Unit Information

Installation Name:			
Dehumidifier Model #:		Serial #:	
Form Completed By (Print):		Signed:	
Company Name:		Date:	
Company Address:		Phone #:	
		Fax #:	
Defective Comp. Model #:		Serial#:	
New Compressor Model #:		Serial#:	

### Compressor Condition at Time of Initial Review

Compressor A			
Continuity (0 resistance) to Ground on one or more legs	<input type="checkbox"/>	Compressor drawing higher current than design	<input type="checkbox"/>
Continuity (0 resistance) between two or more legs (3 phase units)	<input type="checkbox"/>	Compressor drawing locked rotor current	<input type="checkbox"/>
Other (describe):	<input type="checkbox"/>	Runs without pumping: Pressures: ____ / ____	<input type="checkbox"/>
Compressor B			
Continuity (0 resistance) to Ground on one or more legs	<input type="checkbox"/>	Compressor drawing higher current than design	<input type="checkbox"/>
Continuity (0 resistance) between two or more legs (3 phase units)	<input type="checkbox"/>	Compressor drawing locked rotor current	<input type="checkbox"/>
Other (describe):	<input type="checkbox"/>	Runs without pumping: Pressures: ____ / ____	<input type="checkbox"/>

### Final Determination of Failure

Liquid Floodback	<input type="checkbox"/>	Low Superheat	<input type="checkbox"/>
Low Sump Oil	<input type="checkbox"/>	Insufficient Motor Cooling	<input type="checkbox"/>
Debris	<input type="checkbox"/>	Defective Expansion Valve	<input type="checkbox"/>
Other (Describe):			

### Diagnostic/Corrective Action Summary

Describe what corrective action was taken to prevent a repeat failure


### Compressor Replacement Checklist

Required	<input type="checkbox"/>	Choose One	<input type="checkbox"/>	For Test Results Showing Acid or Particulate	<input type="checkbox"/>
Acid and particulate test completed	<input type="checkbox"/>	Unit Evacuated to 500 microns absolute and vacuum decay passed	<input type="checkbox"/>	HH Cores used - Acid Core	<input type="checkbox"/>
Liquid Line Filter Replaced	<input type="checkbox"/>	Alternate triple evacuation process used	<input type="checkbox"/>	SF filter used	<input type="checkbox"/>

**Air Flow Readings:** Refer to Installation and Operations manual for correct balancing procedures

Evap A Static Pressure Drop (Cool Thru Damper)	"WC	Supply Duct Static Pressure Drop	"WC
Evaporator Static Pressure Drop (Evaporator Bypass Damper)	"WC	Return Duct Static Pressure Drop	"WC

### Temperature Readings

Room Air Temperature	°F	Water Temp (Circle: Pool / Tower)	°F	Room Relative Humidity	%
Outdoor Air Temperature	°F	Water Temp (Circle: Pool / Tower)	°F	Outdoor Relative Humidity	%

### Compressors and Refrigeration in Reheat Mode

	Circuit A	Circuit B
Motor # (See wiring schematic for details)		
Discharge Pressure		PSIG
Liquid Line Pressure (At access fitting nearest TXV)		PSIG
Suction Pressure (At compressor)		PSIG
Liquid Line Temperature (At access fitting nearest TXV)		°F
Suction Temperature (At Compressor)		°F
Refrigerant Sight Glass Condition (Clear, Intermittent Vapor, Flashing)		
Comp. Oil Level Sight Glass (Shut down comps., wait 5 minutes)	1/2 3/4 F	1/2 3/4 F

### Compressors and Refrigeration in Cooling Mode

	Circuit A	Circuit B
Motor # (See wiring schematic for details)		
Discharge Pressure		PSIG
Liquid Line Pressure (At access fitting nearest TXV)		PSIG
Suction Pressure (At compressor)		PSIG
Liquid Line Temperature (At access fitting nearest TXV)		°F
Suction Temperature (At Compressor)		°F
Refrigerant Sight Glass Condition (Clear, Intermittent Vapor, Flashing)		
Comp. Oil Level Sight Glass (Shut down comps., wait 5 minutes)	1/2 3/4 F	1/2 3/4 F



**OPTIMIZING SOLUTIONS THROUGH SUPERIOR DEHUMIDIFICATION TECHNOLOGY**

N120 W18485 Freistadt Road • Germantown, WI 53022 • E-mail: [info@desert-aire.com](mailto:info@desert-aire.com)

---

Ph: (262) 946-7400 • Fax: (262) 946-7401 • Website: [www.desert-aire.com](http://www.desert-aire.com)